

SNMP PremNet™ 5000 Manager for Windows

User's Guide

13D475A-7/B 12/96

Milgo Solutions, Inc.

1619 N. Harrison Parkway

P.O. Box 407044

Fort Lauderdale, FL 33340-7044

Internet: <http://www.milgo.com>



Warranty

The period of warranty for this product starts on the date of sale to the original purchaser and extends 90 days for software. Refer to Milgo Solutions, Inc. Limited Warranty for details.

Milgo Solutions requires a Return Material Authorization (RMA) prior to the return of any equipment under the provisions of the warranty. Please contact your authorized reseller or the nearest Milgo support center for details.

Second Edition, December, 1996

PremNet and CMS are trademarks of Milgo Solutions, Inc. All other logos and product names are trademarks or registered trademarks of their respective companies.

©1999 Milgo Solutions, Inc.

All rights reserved. No part of this work covered by the copyright hereon may be reproduced or copied in any form or by any means — graphic, electronic, or mechanical, including photocopying, recording, taping, or information and retrieval systems — without written permission of the publisher. Any software furnished under a license may be used or copied only in accordance with the terms of such license.

Milgo Solutions, Inc. reserves the right to modify or revise all or part of this document without notice and shall not be responsible for any loss, cost, or damage, including consequential damage, caused by reliance on these materials.

Printed in U.S.A.

Milgo Solutions

Customer Information Contacts

CORPORATE HEADQUARTERS

Milgo Solutions, Inc.
1619 North Harrison Parkway
Sunrise, Florida 33323-2802, U.S.A.
Tel: (954)-846-1601/(800)-333-4143
Fax: (954)-846-3935
Internet: <http://www.milgo.com>

Call Milgo's Corporate Headquarters if you need the following information:

Press	For:
1	Billing or invoice information
2	Orders, product delivery or availability, and repairs
3	Sales
4	Field service
5	Training
6	Employee benefits and information
7	Corporate quality
8	Mailing or street addresses

For technical support, please contact your supplier/distributor with details of the issue.

MILGO SERVICE CONTRACT CUSTOMERS:

For customers with Milgo Service Contracts or service requirements, contact the following offices:

AMERICAS

U.S. and U.S. Multinational

Milgo Solutions, Inc.
1619 North Harrison Parkway
Sunrise, Florida 33323-2802
Tel: (954)-846-4569/(800)-366-0126
Fax: (954)-846-1137

EUROPE/MIDDLE EAST/AFRICA

Milgo Solutions, Ltd
Landata House, Station Road
Hook, Hampshire, RG279JF, England
Tel: +44 (0) 1256 763911
Fax: +44 (0) 1256 764717

Milgo Solutions SA
Parc du Colombier
18 Rue Jules Saulnier
93206 Saint-Denis
Cedex, France
Tel: +331 (0) 49 33 5800
Fax: +331 (0) 49 33 5851

Milgo Solutions BV
Poortweg 14
2612 PA Delft
The Netherlands
Tel: +31 15 269 82 82
Fax: +31 15 262 18 08

ASIA/PACIFIC

Contact your Milgo affiliate support center. (See next page for addresses and phone/fax numbers.)

MILGO AFFILIATE SUPPORT CENTERS:

AMERICAS Region

Milgo Solutions, Inc.
1619 North Harrison Parkway
Sunrise, Florida 33323-2802, U.S.A.
Tel: (954)-846-6116/(888)-722-2548
Fax: (954)-846-3692
email: support@milgo.com

EUROPE/MIDDLE EAST/AFRICA Region

Milgo Solutions, Ltd.
Landata House, Station Road
Hook, Hampshire, RG279JF, England
Tel: +44 (0) 1256 761240
Fax: +44 (0) 1256 382112
email: support.centre@milgo.com
Internet: www.milgo.com/emea
Bulletin Board Service: +44 1256 766608 (PSTN)
+44 1256 744832/3/4 (ISDN)

MILGO AFFILIATE SUPPORT CENTERS:

ASIA/PACIFIC Region

Milgo Solutions (Hong Kong), Ltd.
Sun House 6th Floor
181 Des Voeux Road, Central
Hong Kong
Tel: 852-2815-1886
Fax: 852-2815-2895

Milgo Solutions (Hong Kong) supports:

- China (southern provinces)
- Japan
- Korea
- Hong Kong
- Macau
- Taiwan

Milgo Solutions (Singapore) Pte Ltd.
26 Ayer Rajah Crescent, #04-06
Ayer Rajah Industrial Estate
Singapore 139944
Tel: +65 779 2200
Fax: +65 778 5400

Milgo Solutions (Singapore) supports:

- Brunei
- Indonesia
- Malaysia
- Philippines
- Singapore
- Thailand
- Australia
- New Zealand
- Rest of Indochina
 - Cambodia
 - Laos
 - Myanmar
 - Vietnam

Milgo Solutions (Beijing), Inc.
Room 20659
Beijing Friendship Hotel
Beijing 100873
Tel: 86-10-6849-8731
Fax: 86-10-6849-8732

Milgo Solutions (Beijing) supports:

- China (northern provinces)

About This Manual

Manual Description

The *SNMP PremNet™ 5000 Manager for Windows User's Guide* describes the features and functions of the PremNet 5000 Manager in the CMS™ 400 environment and on the HP OpenView™ for Windows™ management platform (referred to as OpenView). It is designed to help you configure and manage your SNMP PremNet 5000 Manager Module. Where no distinction is made between CMS 400 or HP Openview for Windows, information given is applicable to both environments.

This manual consists of the following chapters:

- **Chapter 1 - Introduction** provides an overview of SNMP PremNet 5000 network and the supported I/O modules.
- **Chapter 2 - Managing the SNMP PremNet 5000 Network** provides detailed information for connection, configuration, and setup of your SNMP PremNet 5000 System.
- **Chapter 3 - Managing Specific I/O and Link Modules** provides you with configuration, monitoring, and testing procedures on the supported SNMP PremNet 5000 I/O modules.
- **Chapter 4 - Reports** provides you with network and nodal reports about the configuration of your SNMP PremNet 5000 System.

Related Documentation

For further information about PremNet 5000, refer to the following manuals:

- *PremNet 5000 System Installation and Configuration Manual* (# 950-1460-00) for information about how to install and configure the PremNet 5000 chassis.
- *PremNet 5000 I/O Module Management Manual* (# 950-1461-00) for information about the specific I/O modules associated with the PremNet 5000 chassis.
- *PremNet 5000 Asynchronous Transfer Mode (ATM) I/O Module Administrator's Guide* (950-1478-00)
- *PremNet 5000 SONET/SDH Link Module Administrator's Manual* (950-1483-00)
- *PremNet 5000 T3 Link Module Administrator's Guide* (950-1488-00)

- *PremNet 5000 Video I/O Modules Administrator's Guide* (950-1477-00)

If you are running this application on the HP OpenView for Windows management platform, refer to the following manuals for additional information:

- *Racal Device Managers for HP OpenView for Windows Installation Instructions* (Part No. 13D50A-14) explains application requirements and installation instructions in the HP OpenView environment.
- *HP OpenView for Windows User's Guide* describes the features and functions of HP OpenView.

Suggested Reading

This manual assumes that you are familiar with the Windows user interface and have a basic understanding of networks and Simple Network Management Protocol (SNMP). If you need supplemental information about networks, you may find the following publications useful:

- *How Networks Work*. An introductory overview of networks and general concepts, by Derfler and Fang, Ziff-Davis, Publisher
- *The Simple Book - An Introduction to Management of TCP/IP Networks*. A description of network management including SNMP, by Marshall T. Rose, Prentice-Hall, Publisher
- *An Introduction to Network Management*. The basics of network management, by Leinwand and Fang, Addison Wesley, Publisher
- *PC/TCP Interoperability*. A description of the components in network software and how they work together. ftp Software, Inc., Publisher

If you installed applications to run under HP OpenView, you will find descriptions of application-specific functions in the application documentation.

Terminology and Conventions

This manual uses the following typographical conventions:

- Text displayed by the system is shown in System non-bold type: Login.
- Characters that you must input are indicated in System boldface type:

Login **System**

- Special keys that are pressed on a keyboard are shown in brackets: Press [Enter].

Table of Contents

Chapter 1 – Introduction

About Your SNMP PremNet 5000 System for Windows.....	1-1
Node Types	1-2
System Master Node.....	1-2
Interconnect Node.....	1-2
Network Nodes	1-3
Enhanced Network Management Module.....	1-3
CMS 400 for Windows	1-3
HP OpenView	1-3
Accessing the SNMP PremNet 5000 Manager	1-4
Via the CMS 400	1-4
Via HP OpenView	1-5
I/O Modules	1-5
Ethernet I/O Module.....	1-5
High-Performance Ethernet I/O Module.....	1-6
Token Ring 4-Mbps I/O Module	1-6
Token Ring 4/16-Mbps I/O Module.....	1-6
RS-232 4-Port I/O Module	1-6
RS-422 I/O Module	1-6
V.35 I/O Module.....	1-7
4-Wire Voice Card I/O Module.....	1-7
Video I/O Module.....	1-7
T1/E1 I/O Module	1-7
3270 8/32-Port I/O Module	1-7
5250 8-Port and 4-Port I/ O Modules	1-8
Asynchronous Transfer Mode (ATM) I/O Module.....	1-8
Link Modules	1-9
SONET/SDH Link Module	1-9
T3 Link Module.....	1-9

Chapter 2 – Managing the SNMP PremNet 5000 Network

Introduction.....	2-1
Connecting the Management Station	2-1
Adding SNMP PremNet 5000 to the Database	2-2
Via CMS 400	2-2
Via HP OpenView	2-2
HP OpenView - Racal Customizing.....	2-3
Customize Racal Management	2-3
Login Security Levels.....	2-3
Verifying Communication.....	2-4
Via CMS 400	2-4
Via HP OpenView	2-4

Table of Contents

Displaying the SNMP PremNet 5000 Network.....	2-4
Multi-Ring Level Display	2-5
Single-Ring Level Display	2-8
Node Level Display.....	2-11
Service Affecting Commands.....	2-12
Network Configuration (Service Affecting)	2-12
Ring Configuration (Service Affecting)	2-13
Node Configuration (Service Affecting)	2-14
Configuring Connections.....	2-15
Adding New Connections	2-16
Adding Connections Using The Dialog Box	2-17
Adding Connections Graphically.....	2-17
Modifying a Connection	2-19
Deleting a Connection.....	2-20
Renaming a Connection.....	2-22
Tools	2-22
Alarms.....	2-23
Monitor.....	2-24
Status	2-25
Details	2-25
Test.....	2-26
Connections.....	2-26
Configure.....	2-26
Criteria	2-27
Unit, Site, and Group.....	2-27
Ping SMN.....	2-27
Via CMS 400.....	2-27
Via HP OpenView.....	2-27
Direct SNMP	2-28
Via CMS 400.....	2-28
Via HP OpenView.....	2-28
Cancel.....	2-29
Refresh	2-29
Reports	2-30
PremNet Trap Handling.....	2-30
Via CMS 400.....	2-30
Via HP OpenView.....	2-30

Chapter 3 – Managing Specific I/O and Link Modules

Introduction	3-1
Displaying a SNMP PremNet 5000 I/O Node.....	3-1
Node Level Display	3-1
Displaying a SNMP PremNet 5000 I/O Module	3-2
Displaying the Port Level of an I/O Module	3-2
Tools Menu for I/O and Link Modules	3-3
I/O Modules	3-5
Ethernet I/O Module.....	3-5
Configuration Strategy	3-5
Configuring the Module	3-6
Monitoring Statistics	3-7
Resetting Counters.....	3-9
Performing Tests	3-10
Local Segment Test.....	3-10
Fiber Backbone Test	3-12
Halt Current Test.....	3-12
High-Performance Ethernet I/O Module	3-12
Configuration Strategy	3-12
Configuring the Module	3-14
Monitoring Statistics	3-16
Resetting Counters	3-16
Performing Tests	3-17
Token-Ring 4/16 Mbps I/O Module	3-17
Configuration Strategy	3-17
Configuring the Module	3-18
Displaying the Status	3-19
Monitoring Traffic.....	3-20
Resetting Counters	3-21
Performing Tests	3-22
Loop Test	3-22
Reset Loop Test	3-24
Mau/Cable Test.....	3-24
Token-Ring 4 Mbps I/O Module	3-24
Configuring the Module	3-24
RS-232 4-Port I/O Module.....	3-25
Configuring the Module	3-25
Monitoring the Status	3-27
RS-422 I/O Module.....	3-27
Configuring the Module	3-27
Configuring the Port for DTE.....	3-28
Configuring the Port for DCE	3-29
V.35 4-Port I/O Module	3-31
Configuring the Module	3-31
Configuring the Port for DTE.....	3-32
Configuring the Port for DCE	3-33

4-Wire Voice I/O Module.....	3-34
Configuring the Module.....	3-34
Configuring a 4-Wire Voice Card at the Port Level	3-34
Video I/O Module.....	3-36
Configuration Strategy.....	3-36
Configuring the Module.....	3-36
T1/E1 I/O Module	3-38
Configuring the Module.....	3-39
Monitoring the Status.....	3-40
Performing Tests	3-41
3270 8/32-Port I/O Module	3-41
Configuring the Module.....	3-41
Establishing Port Connections	3-42
8-Port Card	3-42
32-Port Card	3-43
5250 8-Port and 4-Port I/O Modules	3-44
Configuration Strategy.....	3-44
Configuring the Module.....	3-45
Establishing Port Connections	3-46
Reset Rx Frame Synchronization	3-47
ATM I/O Module.....	3-47
Configuration Strategy.....	3-47
Configuring the Module Settings.....	3-47
Configuring the Virtual Path.....	3-50
Adding a Virtual Path.....	3-51
Deleting a Virtual Path	3-52
SONET/SDH Link Module	3-53
Configuration Strategy.....	3-53
Configuring the Module.....	3-53
T3 Link Module.....	3-55
Configuration	3-55

Chapter 4 – Reports

Introduction	4-1
Network Revision Report	4-1
Generating a Network Revision Report.....	4-1
Nodal Configuration Report	4-3
Generating a Nodal Configuration Report.....	4-3
Cancel Reports.....	4-5

Figures

2-1	CMS 400 Commands	2-5
2-2	Select Units By Criteria	2-6
2-3	Select Units For Criteria	2-6
2-4	Unit Selection.....	2-7
2-5	Multi-Ring View	2-7
2-6	Single-Ring View.....	2-9
2-7	SNMP PremNet Node View	2-11
2-8	Configuration Warning	2-12
2-9	Network Configuration (Service Affecting)	2-12
2-10	Ring Configuration (Service Affecting)	2-13
2-11	Node Configuration (Service Affecting)	2-14
2-12	Connection Configuration.....	2-16
2-13	Connection Name.....	2-16
2-14	Adding New Connection.....	2-17
2-15	Adding New Connection (Graphical)	2-18
2-16	Modify Existing Connection.....	2-19
2-17	Modifying Existing Connections (Graphical).....	2-20
2-18	Deleting Existing Connection	2-21
2-19	Delete Existing Connection (Graphical).....	2-21
2-20	Tools Menu	2-22
2-21	Alarm Selection.....	2-23
2-22	Alarm Display	2-24
2-23	Token Ring Monitor Display	2-25
2-24	Card Status Display.....	2-25
2-25	Details Display Screen	2-26
2-26	Token Ring Test Screen Display	2-26
2-27	Configuration Screen Display	2-27
2-28	Direct SNMP Control Screen.....	2-28
2-29	Refresh Topology.....	2-29
3-1	SNMP PremNet Node View	3-2
3-2	Port Level Screen	3-3
3-3	EtherNet Configuration.....	3-7
3-4	Ethernet I/O Module Monitor Screen	3-8
3-5	EtherNet Test Selections.....	3-10
3-6	EtherNet Test	3-11
3-7	High Performance Ethernet I/O Module Configuration Screen	3-15
3-8	Token-Ring 4/16-Mbps I/O Module Configuration Screen.....	3-18
3-9	Token-Ring 4/16-Mbps I/O Card Status.....	3-20
3-10	Token-Ring Monitor	3-21
3-11	Token Ring Test.....	3-22
3-12	Token-Ring 4 Mbps I/O Module Configuration Screen	3-25
3-13	RS-232 Port Configuration	3-26
3-14	RS-422 Port Configuration (DTE).....	3-28
3-15	RS-422 Port Configuration (DCE).....	3-29
3-16	V.35 Port Configuration (DTE)	3-32
3-17	V.35 Port Configuration (DCE).....	3-33
3-18	Example of Changing the Port Assignment.....	3-35

3-19	Video I/O Module Configuration Screen	3-37
3-20	DS1 Port Configuration	3-39
3-21	3270 Card Configuration Screen	3-42
3-22	3270 Port Configuration	3-43
3-23	Port Selection.....	3-44
3-24	5250 Card Configuration	3-45
3-25	Establishing Port Connections.....	3-46
3-26	ATM Configurator	3-48
3-27	ATM Interface Configuration.....	3-49
3-28	ATM Configurators	3-51
3-29	Virtual Path Configuration	3-51
3-30	Virtual Path Configuration (ATM Modules).....	3-52
3-31	OC3 SONET/SDH Link Configuration.....	3-54
3-32	T3 Link Configuration.....	3-56
4-1	Network Revisions Report Selection.....	4-2
4-2	Network Revision Report	4-2
4-3	Nodal Configuration Report	4-4

Tables

2-1	Login Security Levels.....	2-3
2-2	SNMP PremNet Ring Display	2-9
2-3	SNMP PremNet Ring Display Component Status	2-10
2-4	SNMP PremNet Ring Display Dynamic Data Flow	2-10
2-5	Direct SNMP Control	2-29
3-1	Tools Menu.....	3-4
3-2	Ethernet I/O Monitor Field Descriptions.....	3-9
3-3	High-Performance Ethernet I/O Module Configuration Parameters.....	3-15
3-4	RS-422/V.35 Configuration Fields.....	3-30
3-5	Configure Video I/O Module Parameters.....	3-38
3-6	Configuration Modifiable Parameters	3-50
4-1	Network Revision Report Information	4-3
4-2	Nodal Configuration Report Information.....	4-4

Chapter 1

Introduction

About Your SNMP PremNet 5000 System for Windows

The SNMP PremNet 5000 is a fiber optic backbone system configured in a ring topology. Each ring can have up to 16 nodes. One of the nodes is dedicated as the master node and connected to the management system through a network hub. This allows you to configure and monitor the entire network from one central location.

Each PremNet node supports up to eight I/O interface modules. These connect the PremNet 5000 System to LANs, mainframe computers, data communication, and audio and video applications.

Time-division multiplexing (TDM) is used to dedicate the bandwidth needed for each application. This enables the fiber optic backbone connected to link modules to carry data, voice and video traffic between nodes.

The SNMP PremNet 5000 has a counter-rotating architecture that maintains system integrity in the event of a node failure or fiber optic failure between two nodes.

The previous PremNet networks were always composed of a single logical ring. The latest release of the product allows multiple rings to connect and have a master node that controls the entire network.

The topology of a network can be as basic as a single standalone node, or as complex as multiple rings with multiple nodes on each ring. The application described herein supports all the following configurations:

- Single-node
- Single-ring , Multi-node
- Multi-ring, Multi-node

This Windows™-based application provides you with an easy-to-use graphical interface for managing your PremNet 5000 Manager. You can quickly select any management function using pulldown menus or toolbar buttons. Graphic displays make it easy for you to analyze management information. If you need guidance with any procedure, context-sensitive on-line help is always a mouse click away.

The SNMP PremNet 5000 Manager is intended to provide management capabilities to the PremNet 5000 product. The PremNet 5000 Manager application can operate on the following network management platforms:

- Milgo Solutions Communications Management Series (CMS) 400
- Hewlett-Packard HP OpenView for Windows

Note: This application is designed to manage the PremNet 5000 units that support the SNMP management protocol. To manage earlier models that do not support SNMP, use the PremNet 5000 Manager for T7 module. See the *CMS 400 PremNet 5000 Manager User's Guide* for instructions.

Node Types

A multi-ring network is constructed by interconnecting a number of single ring SNMP PremNet networks. The latest multi-ring feature uses the Enhanced Network Management Module (ENMM) and multi-ring firmware. The enhanced nodes are subdivided into the following types:

1. System Master Node
2. Interconnect Node
3. Network Nodes

System Master Node

The *System Master Node* (SMN) provides a central point of access for *Network Management Station* (NMS) control. A network management station accessing the SMN in a multi-ring network has a global view of the network. Through the System Master Node, a NMS can be used for the following:

- view the global network topology
- build inter-ring virtual circuits
- view global alarm logs
- view configuration databases
- access remote nodes or modules

This is accomplished by a newly implemented inter-node routing and communications protocol. There is only one SMN in a given “connected” multi-ring network. The SMN is always node number one in Ring 1.

Interconnect Node

The *Interconnect Node* (IN) is used to interconnect two single rings in a multi-ring network. This node contains at least two link modules (one in each of the Link 1 and Link 2 chassis locations, which are used to connect the node on both Ring 1 and Ring 2). The interconnect node is essential to the routing of messages between all nodes in a multi-ring network. Additionally, the IN provides the ring-to-ring timeslot mapping function required for the creation of inter-ring virtual circuits.

Network Nodes

All nodes which are neither the System Master Node (SMN) nor Interconnect Nodes (IN's) are considered to be Network Nodes. Network nodes are nodes which contain either old NMMs or new ENMMs. In a multi-ring network, a *Network Node* (NN) is connected to only one single ring.

Enhanced Network Management Module

The Enhanced Network Management Module (ENMM) enables you to configure and manage any module in any node in the SNMP PremNet 5000 System. The ENMM issues commands through the backplane of the SMN. Commands are then sent through the fiber backbone to the appropriate nodes of the network.

CMS 400 for Windows

The SNMP PremNet 5000 System is managed by the CMS 400 workstation which is attached to a network hub. The hub connects to the AUI or Thinnet port on the Enhanced Network Management Module (ENMM) installed in the System Master Node. This User's Guide describes how to manage your system using either the CMS 400 workstation, or the HP OpenView for Windows platform described below. For information about how to manage PremNet 5000 from a terminal, see the *PremNet 5000 System Installation and Configuration Manual*.

CMS 400 allows you to manage your SNMP PremNet 5000 in various ways. You have the ability to access, view, add, modify, delete, and test specific I/O and link modules within your SNMP PremNet 5000 chassis.

This manual describes the various I/O and link modules that can be managed in the SNMP PremNet 5000 Chassis. For specific information about the various modules, see the *PremNet 5000 System Installation and Configuration Manual* and the *PremNet 5000 I/O Module Management Manual*.

HP OpenView

HP OpenView for Windows is a "platform" for network management programs. It provides a standard graphic interface so that multiple network applications can share a common display and alarm system. In addition, it provides basic network management functions to interface with devices on the network. The functionality provided for the CMS 400 and for HP OpenView for Windows are the same, with some differences in database, map and alarm features.

HP OpenView for Windows consists of:

- Maps
- Autodiscovery
- Alarms
- SNMP Manager

HP OpenView for Windows SNMP platform is a PC Windows-based, entry-level, integrated management system. The HP OpenView for Windows systems are small, single-user, and manage a limited number of SNMP devices. Applications from many vendors can be integrated together on the HP platform.

CMS management applications integrated with HP OpenView for Windows is a network management product for Microsoft Windows that provides management capabilities for Milgo SNMP managed network devices. These capabilities of HP OpenView include a network map showing the devices in a network, and an integrated alarm log where all events are displayed regardless of which application discovered the condition.

HP OpenView also consists of a SNMP command stack and communication utilities. Refer to the *HP OpenView for Windows User's Guide* for detailed information.

Accessing the SNMP PremNet 5000 Manager

Via the CMS 400

Communications Management Series (CMS) 400 kernel is the base software that runs non-Microsoft Windows and Microsoft® Windows™ workstations. It also contains the code needed for the hub to manage your SNMP PremNet 5000 products. The new CMS 400 for Windows application, called **WPREMNET**, supports PremNet 5000 SNMP multi-ring (as well as single ring and standalone). Many PremNet management features that currently spread across several T7 applications today are concentrated here.

Although the code for managing your SNMP PremNet 5000 products is embedded within the CMS 400 software, it can only be accessed by installing the proper key module which literally "turns on" access to your SNMP PremNet 5000 products.

Note: The SNMP PremNet 5000 Manager key module is a separately-purchased option to your CMS 400 System.

When a module (key) is installed on a hub, unit types supported by that key may be added to the database. The number of units that may be added is limited by the key.

Refer to the *CMS 400 Installation Manual*, Chapter 3, for instructions about installing key modules.

Via HP OpenView

An HP OpenView for Windows application, called Communications Management Series for HP OpenView (**CMSOV**), supports the PremNet 5000 SNMP Manager access from the HP OpenView environment. When HP OpenView runs, CMSOV, which was created during installation, executes as well. CMSOV registers to receive map events. The HP OpenView maps contain all the information necessary to draw a picture of your network. A map is made up of one or more submaps, usually organized in a hierarchy. Submaps allow you to create several views of your network to simplify management. Submaps are composed of icons, or symbols. An icon may represent one of the following:

- An equipment, such as a computer, printer, or access device.

Whenever you double-click the left mouse key on the **PremNet 5000** symbol, control is passed to CMSOV to take appropriate action. A popup menu appears with selectable options available for managing the PremNet 5000 network.

Although HP OpenView for Windows is intended to be a common integration platform for multiple vendor management applications, the rules governing unintentional interactions between such applications are not well defined.

HP OpenView for Windows supports the PremNet 5000 product alongside existing support for other Milgo products.

For complete information about HP OpenView features, refer to the *HP OpenView for Windows User's Guide*.

For software installation instructions, refer to the *Racal Device Managers for HP OpenView for Windows Installation Instructions*.

I/O Modules

Ethernet I/O Module

The Ethernet I/O Module is a full-forwarding bridge (non-filtering) that allows you to connect multiple Ethernet segments or networks. The Ethernet module provides three types of connections to the local Ethernet segment:

- Attachment Unit Interface (AUI) (female DB15) for connection to a MAU.
- Thin Ethernet coax interface (BNC) for connection to a 10BASE2 segment.
- Media Access Unit interface (MAU) (male DB15) for connection to a bridge or other AUI port.

High-Performance Ethernet I/O Module

The High-Performance Ethernet I/O module provides full bandwidth Ethernet remote connectivity between Ethernet segments or networks connected to the SNMP PremNet 5000 System. With this module, you can connect remote Ethernet networks through the SNMP PremNet 5000 fiber backbone. This gives you the same functionality as if all connected devices were together on the same logical 10 Mbps network, even though those devices may be separated by long distances.

- Attachment Unit Interface (AUI) (female DB15) for connection to a MAU.
- Thin Ethernet coax interface (BNC) for connection to a 10BASE2 segment.
- Media Access Unit interface (MAU) (male DB15) for connection to a bridge or other AUI port.
- Backward compatible to the Standard Ethernet I/O card.
- Up to four timeslots may be selected.

Token Ring 4-Mbps I/O Module

The Token-Ring 4-Mbps I/O Module enables you to transport Token-Ring data across the fiber backbone. This module provides eight RJ45 ports for connecting devices and a RI/RO interface for connecting additional standalone MAUs.

Token Ring 4/16-Mbps I/O Module

The Token-Ring 4/16-Mbps I/O Module enables you to transport Token-Ring data across the fiber backbone. This module provides four DB9 lobe ports for connecting devices and a RI/RO interface for connecting additional standalone MAUs.

RS-232 4-Port I/O Module

The RS-232 4-Port I/O Module has asynchronous and synchronous data communication via four RS-232 interface ports at speeds up to 38.4 Kbps. Each port on the module is independently configurable.

RS-422 I/O Module

The RS-422 I/O Module has asynchronous and synchronous data communication via four DB25 connectors with speeds up to 2.048 Mbps. Each port on the module is independently configurable. This module supports four different clock configurations: external synchronization, internal synchronization, slave, and asynchronous.

V.35 I/O Module

The V.35 I/O Module has asynchronous and synchronous data communication via four V.35 interface ports at speeds of up to 2.048 Mbps. Each port on the module is independently configurable. This module supports the standard Winchester connections.

4-Wire Voice Card I/O Module

The 4-Wire Voice Card I/O Module provides a bidirectional analog interface suitable for transporting up to eight voice or voice band-data (300 to 3400 Hz) circuits to another interface module located within a SNMP PremNet 5000 network.

Video I/O Module

The SNMP PremNet 5000 Video I/O Modules enable you to communicate video/audio information from a central site to groups of users at remote sites. In addition, teleconferencing offers the advantages of transmitting documents, charts, pictures, and other visuals that can be sent over a standard television monitor.

T1/E1 I/O Module

"T1" and "E1" are used to differentiate between the North American (T1) and European (E1) hierarchical voice/data transmission systems used in the digital telephone network. There are six similar I/O modules that differ only in the number of ports, data rate, and physical interface. These I/O modules provide an interface and transport data to a similar module in another SNMP PremNet node. They also provide transparent transmission through the network.

3270 8/32-Port I/O Module

The 3270 8/32-Port I/O Module allows you to connect 3270 devices to the SNMP PremNet 5000 System. The 3270 interface consists of 32 discrete ports, although it can be multiplexed into four 8-port groups, as in 3299 applications. It provides direct transport of up to 8, 16, or 32 ports of non-multiplexed data to and from the controller and peripheral devices. It also provides transport of four ports of pre-multiplexed data to and from a Terminal Multiplex Adapter (TMA) to a remote node where either a TMA is resident or a 32-port interface module is present in the SNMP PremNet 5000 System.

5250 8-Port and 4-Port I/ O Modules

The 5250 I/O Modules transport the 5250 serial bit stream across the fiber backbone using one TDM timeslot. The module is available in either an 8-port RJ-45 type interface or a 4-port Twinax type interface for workstation/controller connectivity. You can connect these modules in a multi-module configuration, such as one controller module with multiple peripheral or multiplexer modules. You can configure the port connection at the module level.

Asynchronous Transfer Mode (ATM) I/O Module

The SNMP PremNet ATM I/O Module enables you to send and receive short, fixed-length packets called "cells" using the ATM transport. The SNMP PremNet 5000 accepts cell traffic from your premise and carries that traffic back into the carrier's backbone ATM network. The ATM I/O module provides a signaling protocol interface that complies with ATM Forum's User Network Interface (UNI) standard. Although cells carry the data over the ATM interface, the internal transport of the data in the SNMP PremNet system is circuit-based. You define the bandwidth that is allocated to carry the traffic between SNMP PremNet nodes.

Link Modules

SONET/SDH Link Module

Synchronous Optical Network (SONET) is the data transmission standard used in the United States, and Synchronous Digital Hierarchy (SDH) is the standard used in Europe. The SONET/SDH link module converts SNMP PremNet backplane data into SONET or SDH frames (the mode is software-selectable), which are transmitted at 155 Mbps over fiber optic cable.

T3 Link Module

The T3 Link module converts PremNet backplane data into the DS3 framed signal. The DS3 frames are transmitted and received at 44,736 Mbps over 75 Ω coaxial cable.

Chapter 2

Managing the SNMP PremNet 5000 Network

Introduction

This chapter discusses how to configure and manage the SNMP PremNet 5000 System and establish connections between the modules.

Before you can configure the system, you must perform the following tasks:

- Set the dip switches on the ENMM. Refer to Chapter 4 of the *PremNet 5000 System Installation and Configuration Manual*.
- Verify that the nodes are linked together using fiber-optic cable or T3 coaxial cable and the common modules are properly installed in the nodes.
- Power up each SNMP PremNet 5000 node and check that no red LEDs are lit.
- Connect the management station to the ENMM (see the following procedure).

Connecting the Management Station

Before you can use the workstation to manage the SNMP PremNet 5000 System, you must complete the following steps. The procedural differences for the CMS 400 and HP OpenView management platforms are described.

1. Specify the IP address for SNMP. Refer to Chapter 5 of the *PremNet 5000 System Installation and Configuration Manual* for instructions.
2. Create a database for the SNMP PremNet 5000 System. Refer to the *CMS 400 User's Guide* or the *HP OpenView for Windows User's Guide* to create a database.
3. Define the SNMP PremNet ring to the database via the procedures applicable to your environment, which are explained next.

Adding SNMP PremNet 5000 to the Database

Via CMS 400

The SNMP PremNet 5000 Master Node (Node 1) is defined by the IP address of the System Master Node. The CMS 400 system can be used to manage all nodes in the SNMP PremNet 5000 network.

To add a SNMP PremNet 5000 Network to the CMS 400 database:

1. Select Database from the menu.
2. Select Network Map from the Database menu or click on the Network Map Icon on the toolbar.
3. Select Insert.

The Insert New Unit screen prompts for the address.

The SNMP PremNet 5000 Master Node should be defined completely, with an IP Address and the name of the node. The other SNMP PremNet 5000 nodes in the network are automatically defined by the master node.

4. Set Diagnostic Protocol to SNMP.

Via HP OpenView

Use the HP OpenView Autodiscovery feature to automatically add PremNet units to the database. The HP OpenView Autodiscovery mechanism “discovers” the PremNet devices and displays them on the maps with “PremNet” icons. The PremNet device can be added to the database by two methods:

From the Autodiscovery menu:

1. Select Discovery Manager from the Discover submenu. This is the preferred method.

or

2. Select User-Specified Device from the Configure submenu.

The Autodiscovery function also allows you to specify subnetworks to search and routers to work with. For complete information about using the Autodiscovery feature, refer to the *HP OpenView for Windows User's Guide*.

The attributes may be viewed by either selecting:

- Describe from the Edit menu or
- Right-clicking the PremNet icon and selecting the Describe option with the left mouse button.

HP OpenView - Milgo Customizing

Customize Milgo Management

HP OpenView's main menu bar includes a Milgo-specific choice in the Options menu,, Customize Racal selection. This selection presents a dialog with a grouping called Third Party Application Names. The operator uses this dialog to specify local applications to launch from within Milgo applications and menus.

Three fields are presented:

1. Telnet Application
2. Ping Application
3. TFTP Application

Note: The PremNet Manager does not support Telnet or TFTP applications.

In all cases, the dialog text instructs you to place the token “%s” after the path name as a holder for the IP address of the target unit. The parameter passes the address to the application that is launched. A browse button accompanies each field for convenient selection of an executable file. Refer to the *Racal Device Managers for HP OpenView for Windows Installation Instructions* guide.

Login Security Levels

HP OpenView also offers a three-level security mechanism: a *supervisor* level that can do anything, an *observer* level that can view but make no changes, and an *operator* level that can make changes but cannot reconfigure HP OpenView options.

The popup menu that launches the PremNet 5000 Manager is aware of your login privilege level, and offers only those choices that can be legitimately performed. Table 2-1 lists the applications and the security levels at which they can be executed.

Table 2-1. Login Security Levels

Supervisor	Operator	Observer	Application
x	x		Configure PremNet
x	x	x	Ping SMN

Verifying Communication

Once the SNMP PremNet 5000 network is defined in Network Map and is physically connected to the channel, verify that the CMS 400 or HP OpenView system can communicate with the SNMP PremNet 5000 Master Node.

Via CMS 400

1. Place the cursor on the master SNMP PremNet 5000 Master Node in Network Map.
2. Click on Poll.

If CMS 400 can communicate with the master node, the message Target Device Responds to Poll is displayed. If it cannot, Target Device Does Not Respond is displayed.

Via HP OpenView

1. Double-click with the left mouse button on the PremNet icon in the HP OpenView Submap view. A popup menu offers the following choices:



The image shows a rectangular popup menu with a dark background and light text. It contains two lines of text: "Configure PremNet" on the top line and "Ping SMN" on the bottom line. The menu is slightly offset to the right and bottom.

2. Click on Ping SMN.

If the HP OpenView system can communicate with the master node, the message Target Device Responds to Poll is displayed. If it cannot, Target Device Does Not Respond is displayed.

Device settings and other device information are available as variables and are defined either in a standard Management Information Base (MIB) file or in a custom MIB file provided by the device manufacturer. For more information about the Milgo MIB inclusion, refer to the *Racal Device Managers for HP OpenView for Windows Installation Instructions* guide.

Displaying the SNMP PremNet 5000 Network

The SNMP PremNet is displayed at three levels:

- Multi-Ring Level
- Single-Ring Level
- Node Level

Multi-Ring Level Display

To display the SNMP PremNet 5000 at the multi-ring level:

1. Select LAN Control from the Commands menu in CMS 400 (refer to Figure 2-1).




Figure 2-1. CMS 400 Commands Menu

2. Select PremNet SNMP Control. The “Select One Or Many Units By Criteria” dialog box appears. Refer to Figure 2-2.




Figure 2-2. Select Units By Criteria

3. Select Unit from the dialog box. The available units are listed (refer to Figure 2-3).




Figure 2-3. Select Units For Criteria

4. Select the unit desired by clicking on it, and select OK.

The “Select One Or Many Units By Criteria” screen reappears with the name of the selected unit. Refer to Figure 2-4.




Figure 2-4. Unit Selection

- Click on OK to select the unit.

The program reads the unit's system variables, then displays the MultiRing View (refer to Figure 2-5).

Note: Any node in alarm displays its number in **RED**.




Figure 2-5. MultiRing View

Single-Ring Level Display

To display the SNMP PremNet 5000 at the single-ring level, choose one of the following methods:

Select a single ring by double-clicking on it from the MultiRing view, or select Single-Ring from the View menu, or click on the Single-Ring icon.

When the Single-Ring dialog box appears, highlight the desired ring and select OK.

Note: You must highlight the selection before selecting OK even if there is only one ring listed. If not, an error message appears.

The ring explodes to fill the window with the nodes for that ring (refer to Figure 2-6).

The initial Single-Ring display shows empty boxes. As the data is returned from polling, the boxes are filled. This adds detail (nodal links, switching modules, and I/O modules) and status to each node on the ring.

This gives you a snapshot glimpse of the ring and all the nodes on that ring. At any point during the filling in of the detail, you can select a node for explosion, or back out to the MultiRing display (or any of the other tools provided by active toolbar icons and menus).

Note: Any node in alarm displays its number in **RED**.




Figure 2-6. Single-Ring View

Refer to Tables 2-2, 2-3, and 2-4 for descriptions of the color codes in the Single-Ring Display.

Table 2-2. SNMP PremNet Ring Display

Component	Window Display
Tag Name	Node Title is the Tag Name. Node's ring-node identification displays immediately above the nodes icon.
Link Module Cards	Displayed as separate transmit and receive boxes (A/B/C/D) within each node.
Switch Cards	Displayed as individual boxes (SxA, SxB) within each node.
I/O Cards	Displayed as eight individual slots with a common connection to the active switch within each node.
Fiber data flow between nodes	Displayed as arrows emanating from the link module transmit box of one node and terminating at the corresponding link module receive box of the next node.

Each box within a node is color-coded to reflect the associated component's status (refer to Table 2-3).

Table 2-3. SNMP PremNet Ring Display Component Status

Color	Link/Switch Module	I/O Slot
Green	Card is active	Circuits are active
Blue	Card is in standby	No active circuits
Red	Card is in alarm	Card is in alarm
White	Card not present	Card not present

The dynamic data flow changes within a ring are described in Table 2-4.

Table 2-4. SNMP PremNet Ring Display Dynamic Data Flow

Condition	Effect on Display
Loss of Internode Connection	Boxes representing the corresponding transmit and receive link modules of the affected nodes turn red. Redirection of the affected node's internal data flow arrows between the switch and link modules.
Power Down of Node	The node goes completely white. Link flow adapts to a new route.
Active Switch Change	The switched card changes color according to what was switched in the active node. Arrows representing internal data flow within the node adapt to the use of the new switch card.

If the ring is configured for redundant operation, the arrows representing data flow between node link modules will all go in the same direction. If the ring is configured for counter-rotating operation, these arrows go in the appropriate direction.

Note: There is a separate window per ring. Up to 16 nodes can be displayed on one ring, with up to 16 ring modules for multi-ring configurations.

Node Level Display

To display the SNMP PremNet 5000 at the node level:

1. In the Single-Ring level view, move the arrow or cursor to the node you want to view.
2. Click on the node to select it. Notice that its color changes when selected.

Note: The node selection must be completely colored for you to view the node level.

3. Select Node from the View menu, click on the Node icon, or click on the node picture again.

The node view is displayed (refer to Figure 2-7).




Figure 2-7. SNMP PremNet Node View

Note: Any modules in alarm appear in **RED**.

Service Affecting Commands

Service-affecting commands affect the flow of data in the SNMP PremNet 5000 network. These commands are displayed as settings in dialog boxes when you select Configure from the Tools menu. Warnings similar to the one in Figure 2-8 may be displayed at the network configuration, ring configuration, and node configuration levels described in this section.

Warning: Use extreme caution when changing any of these configuration settings




Figure 2-8. Configuration Warning

Select No to return to the configuration box, or select Yes to accept the changes.

Network Configuration (Service Affecting)

To view the network configuration:

1. Display the MultiRing view.
2. Select Configure from the Tools menu or click on the Configure icon. The Network Configuration (Service Affecting) box appears (refer to Figure 2-9).




Figure 2-9. Network Configuration (Service Affecting)

3. View the current setting in the Ring Configuration field. The selections are as follows:
 - Single Node
 - Multi Node-Single Ring
 - Multi Node-Dual Main
 - Multi Node-Multi Ring
4. Select Cancel to return to the Multi-Ring view.

Note: If you make a change and select OK, Figure 2-8 appears.

Ring Configuration (Service Affecting)

To view a ring configuration:

1. Display the Single-Ring view.
2. Select Configure from the Tools menu or click on the Configure icon. The Ring Configuration (Service Affecting) box appears (refer to Figure 2-10).



Figure 2-10. Ring Configuration (Service Affecting)

3. View the current setting in the following fields:
 - Ring Option
Redundant or
Counter Rotating
 - Management Ring
Mgmt Msgs On AB Ring or
Mgmt Msgs On CD Ring

- Save Current Ring Order
Do Not Save Current Ring Order or
Save Current Ring Order

4. Select Cancel to return to the Single-Ring view.

Note: If you make a change and select OK, a Ring Configuration Warning appears (similar to Figure 2-8).

Node Configuration (Service Affecting)

To view a node configuration:

1. Display the Node view.
2. Select Configure from the Tools menu or click on the Configure icon. The Node Configuration (Service Affecting) box appears (refer to Figure 2-11).




Figure 2-11. Node Configuration (Service Affecting)

3. View the current setting in the following fields.

- Node Type
System Master Node
Interconnect Node Child Ring AB
Interconnect Node Child Ring CD
Network Node

- Active Link

Link A	Link A-C
Link B	Link A-D
Link C	Link B-C
Link D	Link B-D

- Active Switch
 - Switch A or
 - Switch B

- Switch Configuration
 - Redundant or
 - Single

- BackPlane TS Mode
 - 20 Time Slots or
 - 30 Time Slots

- TS Reassignment
 - Do Not Reassign or
 - Assign

4. Select **Cancel** to return to the Node view.

Note: If you make a change and select **OK**, a Node Configuration Warning appears (similar to Figure 2-8).

Configuring Connections

Connections are used to create logical paths between I/O modules within a network. This procedure describes how to add, modify, and delete a connection between two of the same type of modules installed in two separate nodes.

To configure connections from the Ring View:

1. Select **Connections** from the Tools menu or click on the Connections icon from the toolbar. This provides a dialog box to configure connections and timeslot data.

The Connection Configuration screen appears. See Figure 2-12.




Figure 2-12. Connection Configuration

There are two methods of configuring connections. One method is to use the dialog box. The other is to use a graphical representation of the network. Select Display Connections Graphically from the Connection Configuration Display to view the graphical display screen. Both methods are described.

Adding New Connections

To add new connections:

1. Select Add from the Connection Configuration screen. The Connection Name screen appears (refer to Figure 2-13).



Figure 2-13. Connection Name

2. Enter a connection name, if desired, or click on OK to accept the default name.

Adding Connections Using The Dialog Box

When the Adding New Connection dialog box appears, follow the procedure in this section (refer to Figure 2-14).




Figure 2-14. Adding New Connection

1. Select a module from the Available Modules box.
2. Click on the Left Arrow to move the module to the Participating Modules box. The list of modules in the Available Modules box is narrowed down to only the modules of the same type as the one selected.

Note: Double-clicking on a module name moves it to the opposite box.

3. Move any other modules over to the Participating Modules box to create your connection.
4. Click on OK. The Connection Configuration screen appears.
5. Click on Process Connects to establish the connection.

Adding Connections Graphically

The graphic representation of the network is color-coded (refer to Figure 2-15). As you point the arrow on a slot, its description is displayed on the bottom of the screen. Each slot displays one of the following colors:

- Cyan This slot is available and qualified to use in a connection.
- Yellow This slot is available but not qualified to use in a connection.
- Red This slot is used in another connection.
- Blue This slot is now ready to connect.

Note: These colors change as you build the connections.

1. Select a cyan-colored slot by clicking on it. The card in that slot is displayed at the bottom of the screen. After clicking on a cyan slot, it turns blue. This means it is now in the connection.
2. Select other cyan cards you want in your connection and click on them. Those slots turn blue.

The only slots that contain the same type of card are cyan. All other slots have turned yellow.

3. Click on OK when you have finished creating that connection. The Connection Configuration screen appears.
4. Select Process Connects to save the connection.




Figure 2-15. Adding New Connection (Graphical)

Modifying a Connection

To modify a connection:

1. Select Connections from the Tools menu, or click on the Connections icon from the toolbar. The Connection Configuration dialog box appears.
2. Highlight the connection name you want to modify.
3. Select Modify from the Connections dialog box.

The Modifying Existing Connection screen or its graphical counterpart appears (refer to Figure 2-16 or Figure 2-17).

4. Modify your existing connection by moving participating and available modules.
5. Select OK when finished. The Connection Configuration screen appears.
6. Select Process Connects to establish the connection.




Figure 2-16. Modify Existing Connection




Figure 2-17. Modifying Existing Connection (Graphical)

Deleting a Connection

To delete a connection:

1. Select Connections from the Tools menu, or click on the Connections icon.
2. Select the connection you want to delete, and select Delete from the screen.

The Deleting Existing Connection screen or its graphical counterpart appears (refer to Figure 2-18 and Figure 2-19).

3. Select OK from this screen.
4. Select OK from the “Are you certain?” screen. The Connection Configuration screen appears.
5. Select Process Connects to discontinue the connection.




Figure 2-18. Deleting Existing Connection




Figure 2-19. Deleting Existing Connection (Graphical)

Renaming a Connection

To rename a connection:

1. Select Connections from the Tools menu or click on the Connections icon.
2. Select the configuration to rename from the Connection Configuration screen.
3. Select Rename. The Connection Name screen appears.
4. Type in the new name, and click OK. The Connection Configuration screen appears.
5. Select Process Connects to save the configuration.

Tools

Selections available in the Tools menu, and in tool icons on the toolbar, enable you to properly manage the SNMP PremNet 5000 Network. The Tools menu is available at all viewing levels.




Figure 2-20. Tools Menu

Note: Certain menu selections may be grayed out because they are not applicable at a particular viewing level. For example: the Test tool will be grayed out at the MultiRing, Single-Ring, and Node levels. This is because tests apply to specific I/O and link modules. Also, if an I/O or link module has no integral test, the test tool will not be available. See Chapter 3, “Managing Specific I/O and Link Modules”, for additional information.

The following paragraphs give a brief description of the tools in the Tools menu.

Alarms

You can display alarms generated by the system or the SNMP PremNet network.

When the Alarm item is selected from the Tools menu or from the tool bar (Bell icon), the Alarm Selection dialog box gives you the option to select (refer to Figure 2-21):




Figure 2-21. Alarm Selection

- PremNet Alarm Log (queries the PremNet SNM log) or
- CMS 400 Alarm Log (spawns CMS 400's or HP OpenView's system alarm display)

The system displays the actual alarm logs, both current and history, for each level of display (refer to Figure 2-22).

The SNMP PremNet network displays alarms at any network level. Also, an alarm history is available. Alarms appear at the level viewed and below. For example: If you select Alarms at the single ring level, you can view the alarms for the ring and its nodes and modules.

No alarms are displayed for any other nodes or rings in the network. Refer to Figure 2-22 for an example of an alarm screen.




Figure 2-22. Alarm Display

Monitor

Use the Monitor tool to monitor the traffic on the module. An example of using this tool is to monitor LAN traffic on a particular module for errors. Refer to Figure 2-23 for an example of a monitor display screen.




Figure 2-23. Token Ring Monitor Display

Status

Use the Status tool, for example, when you want to check the status of a particular module. Refer to Figure 2-24 for an example of a status display screen.




Figure 2-24. Card Status Display

Details

Use the Details tool, for example, to view specific details of a module. Refer to Figure 2-25 for an example of a details display screen.



Figure 2-25. Details Display Screen

Test

Use the Test tool to perform applicable tests on specific modules and ports of modules. Remember that not all modules have integral tests, therefore the test tool is grayed out if tests are not applicable. Refer to Figure 2-26 for an example of a test screen display.



Figure 2-26. Token Ring Test Screen Display

Connections

Use the connections tool to add, modify, delete, or rename connections between specific modules in the network. Refer to “Configuring Connections” described earlier in this chapter for more information.

Configure

Use this tool to configure parameters on a specific module or port on a module. Refer to Figure 2-27 for an example of a configuration screen display.




Figure 2-27. Configuration Screen Display

Criteria

Unit, Site, and Group

Use the criteria tool to select the Criteria screen, which allows you to select one or many target unit(s) to be used by the application. You create a criteria string which represents a unit or a set of units.

The applications perform their associated functions on all units that match the specified criteria. When you select one of these criteria, then channels, units, sites, or groups on your specified hub are displayed. Select the criteria applicable to your application. Refer to “Multi-Ring Level Display” earlier in this chapter.

Ping SMN

Via CMS 400

Use the Ping tool to Poll the System Master Node (SMN) with an ICMP PING packet. The status message at the bottom of the screen displays whether the device responded or not.

Via HP OpenView

This menu option launches the user-chosen Ping utility (if any) named in the Ping Application field in HP OpenView’s Options menu, Customize Racal selection. A warning message is issued if no such utility is specified.

Direct SNMP

Via CMS 400

Use the Direct SNMP tool to activate the Direct SNMP application. The target unit is displayed to allow access to MIB variables (refer to Figure 2-28). Table 2-5 explains the Direct SNMP functions.

Via HP OpenView

Direct SNMP invokes the HP OpenView SNMP Manager-Define Query function for direct SNMP polls to the PremNet 5000 Manager. Refer to the *HP OpenView for Windows User's Guide* for direct SNMP control.




Figure 2-28. Direct SNMP Control Screen

Table 2-5. Direct SNMP Control

Selection	Function
Ping	The System Master Node (SMN) is polled with an Internet Control Message Protocol (ICMP) ping packet. A message appears indicating whether the unit responded or not.
Alarms	Indicates the date and time of any alarms.
Monitor	Shows a screen to allow setting of monitor options.
Configure	Selects a MIB (Management Information Base) to configure.
Fetch	Fetches objects with a selected MIB.
Telnet	Enables access into Telnet.
Dump	Displays MIB Objects for a selected unit.
IPCache	Displays the IP Address of the unit selected.

Cancel

Use the Cancel tool to terminate other tools already in progress. For example, select Cancel when you want to stop gathering information for a report.

Refresh

Use the Refresh tool to gather slot information again if needed. For example: Use this tool when adding or deleting modules in a node. Refer to Figure 2-29.



Figure 2-29. Refresh Topology

Reports

Use the Reports tool to generate reports about the network. Refer to Chapter 4, "Reports", for generating network and nodal reports.

PremNet Trap Handling

Traps are unsolicited messages (containing management information) generated by an SNMP agent to inform the SNMP client (management station) about a notable event or change of state, for example: coldstart, link failure, threshold exceeded, shutdown, etc. PremNet 5000-specific traps are issued through the master node ENMM. The differences between CMS 400 and HP OpenView are described.

Via CMS 400

All of the PremNet traps are mapped to the Service Request (SRQ) alarm. Each alarm contains detailed textual information in the parameters field describing the alarm condition. Refer to the *CMS 400 User's Guide* for trap handling and alarms, and Appendix B for alarm code diagnostics.

Via HP OpenView

The HP OpenView alarm subsystem provides a central logging and event monitoring facility for all HP OpenView applications. When an alarm is generated, it is assigned one of 10 severity levels. HP OpenView can show the alarm condition on the map by changing the background color of the map symbols. Alarms are saved in an alarm log. An alarm log window allows you to view the logged alarms or events. Alarms remain in the current alarm log until acknowledged programmatically by the PremNet application. Once acknowledged, alarms are saved in the history log for a configurable period of time, after which they are deleted. Refer to the *HP OpenView User's Guide* for more information about trapping and alarms.

Chapter 3

Managing Specific I/O and Link Modules

Introduction

This chapter describes the specific configuration features of the various I/O and link modules. Follow the procedures within this chapter to configure and manage specific I/O and link modules.

Displaying a SNMP PremNet 5000 I/O Node

From the SNMP PremNet 5000 Single-Ring level screen, you can display a detailed graphic representation of a single node. From the node level, you can go one step further and display each module in that node.

Node Level Display

To display the SNMP PremNet 5000 at the Node level:

1. Move the arrow or cursor to the node you want to view in the Single-Ring level view.
2. Click on the node to select it. Notice that its color changes when selected.
3. Select **Node** from the **View** menu, click on the **Node** icon, or click on the node picture again.

The node view is displayed (refer to Figure 3-1).




Figure 3-1. SNMP PremNet Node View

Displaying a SNMP PremNet 5000 I/O Module

Select a module from the Node View by clicking on it. The module color changes to a darker gray.

From this level, you can perform various operations on the module by selecting Tools from the Tools menu or clicking on the operation from the toolbar (non-applicable operations are grayed out).

Displaying the Port Level of an I/O Module

To perform operations from the port level of a module:

1. Click on the specified module from the displayed node view.
2. Click on the port desired. The selected port color changes to a darker gray.

A screen similar to Figure 3-2 is displayed.




Figure 3-2. Port Level Screen

3. Choose the applicable operation from the Tools menu or toolbar.

Tools Menu for I/O and Link Modules

Some tool menu selections do not apply to all levels of the network. If a selection is grayed out, it does not function at that particular level. For example, some I/O and link modules allow you to monitor traffic, while others do not.

Depending on the module, configuration can be selected at the module or port level.

Refer to Table 3-1 for which modules apply to which functions in the tool menu.

- A **M** indicates module level.
- A **P** indicates port level.

Table 3-1. Tools Menu

I/O or Link Module	Tools Menu Selections			
	Monitor	Status	Test	Configure
Ethernets	M		M	M
4 Mbps Token-Ring	M	M		M
4/16 Mbps Token-Ring	M	M	M	M
Token-Ring MAU		M		M
RS-232	P		P	M-P
RS-232 Multi-Port	M-P			M-P
RS-422				M-P
V.35	M-P		P	P
4-Wire Voice	M-P	P	P	P
Video	M			M
T1/E1	M-P	M	P	P
3270				M-P
5250				M-P
ATM	M			M
SONET				M
T3				M

Note: Alarms and Detail are applicable to all I/O and link modules. Connections, Criteria, Ping SMN, and Direct SNMP apply at all levels of the SNMP PremNet 5000 network.

I/O Modules

There are eight I/O slots on an SNMP PremNet 5000 node. Any I/O module can be installed into any one of the eight slots. The following paragraphs describe how to configure and manage each of the currently available I/O modules.

Ethernet I/O Module

The Ethernet I/O Module provides a full-forwarding (non-filtering) bridge function that enables you to connect multiple Ethernet segments. These segments then appear as one logical segment, with all traffic from any one segment appearing as traffic on all other connected segments.

This section describes how to configure and manage the Ethernet I/O module.

Configuration Strategy

This procedure provides an overall strategy when configuring a new Ethernet I/O module into an existing network. The steps are listed below, after which each step is explained in detail.

1. **Establish point-to-point connections between the new Ethernet I/O Modules.** You can connect up to 32 Ethernet I/O Modules in the same connection. There should be no external equipment attached to the Ethernet I/O Modules at this point. Refer to “Configuring Connections” in Chapter 2.
2. **Access one of the new Ethernet I/O Modules.** Refer to “Displaying a SNMP PremNet 5000 I/O Module” within this chapter.
3. **Test the new Ethernet I/O Module.** Refer to “Fiber Backbone Test” within this section.
4. **Check the traffic statistics.** While the backbone test is running, monitor the module. Refer to “Monitoring Statistics” within this section.

The traffic statistics displayed should report 128 frames per second transmitted and received on the fiber backbone.

5. **Check each Ethernet I/O Module in the connection.** The traffic statistics displayed should report 128 frames per second received from the fiber backbone. Additionally, the module should display 128 frames per second transmitted onto its local Ethernet segment, provided that the segment is properly terminated. Refer to “Monitoring Statistics” within this section.
6. **Stop the backbone test on the local I/O module.** Refer to “Halt Current Test” within this section.

7. **Connect the cable to the port.** Once each of the connections has been established and verified, connect the cables to the appropriate port on each of the Ethernet I/O Modules in the connection, and then complete the following procedure:
 - Select one of the Ethernet I/O Modules.
 - Select Configure and choose the appropriate port for that module. Refer to “Configuring the Module” within this section.
8. **Reset the traffic and error counters.** Refer to “Resetting Counters” within this section.
9. **Monitor the traffic on the Ethernet segment and the fiber backbone.** Refer to “Monitoring Statistics” within this section.

If the segment has live traffic, the following information is displayed:

 - The number of packets received every second for that segment.
 - The number of packets transmitted onto the segment every second is also displayed for other segments connected elsewhere in the system.
 - Backbone traffic (receive and transmit) is displayed if any traffic is received from or transmitted onto the local Ethernet segment.
 - If one or more errors display, stop the Monitor display and change the port type to AUI or Ext Bridge (whichever port is not being used) to avoid corruption of the Ethernet network.
10. **Check for errors on either the backbone or Ethernet segment.**
11. **Before you begin using the modules, reset the traffic and error counters.** Refer to “Resetting Counters” within this section.

Configuring the Module

This option allows you to select the connection to the Ethernet I/O Module.

1. Select the Ethernet I/O Module as described previously.
2. Select Configure from the Tools menu or click on the Configure icon.

3. Select the interface port type from the dialog box in Figure 3-3 as follows:

To activate the ...	Select ...
AUI port	AUI
Thin Ethernet port	Thinnex coax
MAU port	Ext Bridge

4. Select OK to save the configuration.



Caution: If you change the port type while live data is being exchanged, the flow of data will be disrupted. Disconnect any cable to the module before you change the port type. After the new port type has been selected, reconnect the cable to the selected port.




Figure 3-3. EtherNet Configuration

Monitoring Statistics

This procedure allows you to monitor traffic on the backbone and the segment. The transmit and receive frame information and the number of frame errors detected are continuously displayed and time-stamped for reference.

From the Ethernet I/O Module:

1. Select Monitor from the Tools menu or click on the Monitor icon. The Ethernet Monitor screen appears. See Figure 3-4 for an example. Table 3-2 explains the fields.
2. Select Fiber/Segment from the lower left corner of the Fiber screen to view the statistics of the applicable test. The current test name appears at the top of the screen.

The screenshot shows a window titled "Ethernet Monitor: Fiber" with the following data:

	Current	Peak	Time/Date
Rx Frames/Sec	0	128	@ 15:11:49 14 Aug 1996
Rx Utilization	0.0%	0.0%	@ 13:44:00 30 Aug 1996
	Size	Time/Date	
Max Rx Frame	0	@ 13:44:02 30 Aug 1996	
Min Rx Frame	0	@ 13:44:03 30 Aug 1996	
Errored Hours	3	Missed Frames	0
Minutes	7	Overflows	1
Seconds	14	Underflows	0
Last Error At	@ 16:25:06 28 Aug 1996		Bad Frames
			14

Buttons at the bottom: Segment, Reset Counts, Cancel.

Figure 3-4. Ethernet I/O Module Monitor Screen

The following example explains how to interpret the data in the Errored Seconds, Errored Minutes, and Errored Hours fields.

Example:

The error counters were reset 10 hours ago.

1. Check the Errored Hour field. If the value in the field is 10, at least one error has occurred every hour for the past 10 hours.
2. Check the Errored Minutes field. If the value in the field is 60, at least one error occurred in any given minute, for a total of 60 minutes within the last 10 hours.
3. Check the Errored Seconds field. If the value in the field is 900, at least one error occurred in any given second, for a total of 900 seconds (15 minutes) within 60 minutes within a 10 hour span.

Missed Frames, Overflows, Under flows, and Bad Frames show the total number of each of these kinds of errors that have occurred since the counts were last reset.

Table 3-2. Ethernet I/O Module Monitor Field Descriptions

Field Name	Description
Rx Frms/Sec Now	The average number of frames per second in which frames of received data have been detected since the counts were last reset.
Rx Frms/Sec Peak	The highest number of frames per second in which frames of received data have been detected since the counts were last reset.
Rx Utilization Now	The average percentage of the total Ethernet bandwidth being used by the traffic received from the Ethernet segment or from the backbone since the counts were last reset.
Rx Utilization Peak	The highest percentage of the total Ethernet bandwidth being used by the traffic received from the Ethernet segment or from the backbone since the counts were last reset.
Max Rx Frm Size	The maximum frame size since the counts were last reset.
Min Rx Frm Size	The minimum frame size since the counts were last reset.
Errored Hours	The number of hours in which errors have been detected since the counts were last reset.
Errored Minutes	The number of minutes in which errors have been detected since the counts were last reset.
Errored Seconds	The number of seconds in which errors have been detected since the counts were last reset.
Last Error At	Displays the time/date that the last error (or errors) was detected.
Missed Frames	The total number of missed frame errors which have been detected since the counts were last reset.
Overflows	The total number of overflow errors which have been detected since the counts were last reset.
Underflows	The total number of underflow errors which have been detected since the counts were last reset.
Bad Frames	The total number of bad frame errors which have been detected since the counts were last reset.

Resetting Counters

Select Reset Counts from the Ethernet Monitor screen to reset the counts to zero.

Performing Tests

The Test option allows you to test a new Ethernet network before live data is sent onto it. Test traffic can be generated onto the local Ethernet segment or onto the PremNet 5000 fiber backbone.

To initiate a test:

1. Select the Ethernet I/O Module as described previously.
2. Select Test from the Tools menu or click on the Test icon.

The system polls the module for the current test status. A Progress box appears showing the percentage of data read.

3. Select one of the options from the Ethernet Test selection box in Figure 3-5. The choices are:
 - Local Segment Test
 - Fiber Backbone Test
 - No Test




Figure 3-5. Ethernet Test Selections

Local Segment Test

This option generates test traffic on the Ethernet I/O module. You can direct the module's output into another module to simulate live traffic to test that module and all the other modules in a connection. Or, you can direct the output onto your own Ethernet network to generate test traffic. The test traffic generated will have no adverse effect on the network other than to increase the traffic volume, which in itself may cause problems on the network. Care must be taken to avoid overburdening a live network with test traffic.

To initiate the test:

1. Select Local Segment Test from the Test selection screen.
2. Enter a number from 10 to 85 in the Load % field.
3. Enter a number from 81 to 1724 in the Frames/Sec field.
4. Select OK to start the test (refer to Figure 3-6).




Figure 3-6. EtherNet Test

While the test is running, the values you entered at the Load % and the Frames/Sec fields appear on the screen. The bytes per packet (which is calculated automatically from the load percentage and number of packets per second) is displayed in the Frm Size field.

For example, if you entered 30% traffic load at a rate of 3000 packets per second, the number of bytes per packet is 117. (This packet size includes source and destination addresses, type field, data field, and FCS bytes.)

5. Select Node View to display the front view of the SNMP PremNet node.
6. Select and monitor the module that is receiving the test traffic to ensure proper module operation. Refer to “Monitoring Statistics” within this chapter.

You can also monitor other modules in the connection to ensure system integrity.

Fiber Backbone Test

This option is used to test the Ethernet I/O Module's ability to transmit Ethernet packets over the backbone to another Ethernet I/O Module in the connection.

Perform this test for each Ethernet I/O Module in each connection to verify the integrity of the connection before it is used to transport live data.

To initiate the test:

1. Select Fiber Backbone Test from the Test selection screen.

A message is displayed indicating that the test is in progress.

2. Select Node View to display the node.
3. Select and monitor the module that is receiving the test traffic to ensure proper module operation. Refer to "Monitoring Statistics" within this chapter.

You can also monitor other modules in the connection to ensure system integrity.

Halt Current Test

This option stops whatever test is running at the time. It must be chosen before you can move from one test to another. You must stop all tests before connecting active Ethernet devices to the Ethernet I/O modules.

To stop a test, select Cancel from the Tools menu or click on the Cancel icon.

High-Performance Ethernet I/O Module

The High-Performance Ethernet I/O Module provides full bandwidth Ethernet remote connectivity between Ethernet segments or networks connected to the SNMP PremNet 5000 System.

This section describes how to configure and manage the High-Performance Ethernet I/O Module.

Configuration Strategy

This procedure provides an overall strategy when configuring a new High-Performance Ethernet I/O Module into an existing network. The steps are listed below, after which each step is explained in detail.

1. Establish a connection for the new High-Performance Ethernet I/O Module.

You can connect up to 32 High-Performance Ethernet I/O Modules in the same connection. There should be no external equipment attached to the High-Performance Ethernet I/O modules at this point. Refer to “Configuring Connections” in Chapter 2.

2. Access one of the new Ethernet I/O Modules and check the configuration.

Refer to “Displaying a SNMP PremNet 5000 Module” within this chapter.

Check that the Port Type field - in the EtherNet Configuration is set the same in each segment so that the Ethernet segments are terminated properly. If they are not the same, change the settings as required. Refer to “Configuring the High-Performance Ethernet I/O Module” within this section.

Repeat Step 2 for each new High-Performance Ethernet I/O Module.

3. Test the new High-Performance Ethernet I/O Module. Refer to “Fiber Backbone Test” within this section.

4. Check the traffic statistics. While the backbone test is running, monitor the module. Refer to “Monitoring Statistics” within this section.

The traffic statistics displayed should report 128 frames per second transmitted and received on the fiber backbone.

5. Check each High-Performance Ethernet I/O Module in the connection. The traffic statistics displayed should report 128 frames per second received from the fiber backbone. Additionally, the module should display 128 frames per second transmitted onto its local Ethernet segment, provided that the segment is properly terminated. Refer to “Monitoring Statistics” within this section.

6. Stop the backbone test on the local I/O module. Refer to “Halt Current Test” within this section.

7. Connect the cables to the port. Once each of the connections has been established and verified, connect the cables to the appropriate port on each of the High-Performance Ethernet I/O Modules in the connection and then complete the following procedure:

- Select one of the High-Performance Ethernet I/O Modules.
- Select Configure from the Tools menu and choose the appropriate port for that module. Refer to “Configuring the Module” within this section.

Note: If you select the EXT BRIDGE port, you might have to enable the Heartbeat or SQE parameter for the bridge or other devices connected.

To enable SQE, refer to Table 3-2. If it is not required, select Disabled. You must disable the heartbeat before you select EXT BRIDGE. Failure to properly select this parameter may result in loss of data.

8. **Reset the traffic and error counters.** Refer to “Resetting Counters” within this section.
9. **Monitor the traffic on the Ethernet segment and the fiber backbone.** Refer to “Monitoring Statistics” within this section.

If the segment has live traffic, the following information is displayed:

- The number of packets received every second for that segment.
 - The number of packets transmitted onto the segment every second is also displayed for other segments connected elsewhere in the system.
 - Backbone traffic (receive and transmit) is displayed if any traffic is received from or transmitted onto the local Ethernet segment.
 - If one or more errors display, stop the Monitor display and change the port type to AUI or Ext Bridge (whichever port is not being used) to avoid corruption of the Ethernet network.
10. **Check for errors on either the backbone or High-Performance Ethernet segment.** Refer to “Displaying Statistics” within this section.

Note: The error display may indicate either “errored” seconds, minutes, and hours, or it may indicate the total number of errors, depending on whether error reporting is Sampled or Totaled.

Configuring the Module

This option allows you to select the connection to the Ethernet I/O Module.

1. Click on the High-Performance Ethernet I/O Module from the node view.
2. Select Configure from the Tools menu, or click on the Configure icon.

A screen similar to Figure 3-7 is displayed. Table 3-3 describes the modifiable fields.




Figure 3-7. High Performance Ethernet I/O Module Configuration Screen

Table 3-3. High-Performance Ethernet I/O Module Configuration Parameters

Field	Description
<p>Current Port Type</p>	<p>Allows you to select the port type to use on the module.</p> <p>To activate the ... Select ...</p> <p>AUI port AUI</p> <p>Thin Ethernet port Thinet coax</p> <p>MAU port Ext Bridge</p> <p>CAUTION: If you select Thinet coax, you must have a properly-terminated Thin Ethernet Cable already attached to the port. Failure to do so will result in the interruption of data traffic through the module. The AUI and the MAU ports may be safely selected even if there is no cable attached to the ports.</p>
<p>Connection Type</p>	<p>Indicates either a multipoint or point-to-point connection. All modules in the connection must show the same value in this field.</p> <p>Multipoint - the module is connected with three or more modules.</p> <p>Point-to-Point - the module is connected in a connection with only two modules.</p> <p>Note: You cannot configure the module for 4-timeslot mode unless the connection type is set to Point-to-Point. Likewise, you cannot change the connection type to Multipoint while the module is in 4-timeslot mode.</p>

Table 3-3. High-Performance Ethernet I/O Module Configuration Parameters (Continued)

Field	Description
Compatibility Mode	<p>Allows the High-Performance Ethernet I/O module be fully backward compatible with prior Ethernet modules.</p> <p>Note: Select this only when the High-Performance Ethernet I/O module must be connected to a connection with earlier versions.</p> <p>You cannot modify this parameter when any of the following conditions occur:</p> <ul style="list-style-type: none"> • The module is active (in a connection) and not in a 2-timeslot mode. • The module is in test mode. <p>Any attempt to modify this parameter when these conditions occur will cause an error message.</p> <p>850038 - The module will configure itself in 2-timeslot mode.</p> <p>850067 - The module will configure itself in 2-timeslot mode.</p> <p>850074 Standard - The module can be configured with 1, 2, 3, or 4 timeslots.</p>
Flow Control	Enables or disables the flow control mechanism.
SQE	Enables or disables the IEEE 802.3-specified SQE or Heartbeat function for the MAU port. The bridge or other device connected to the port may or may not require this parameter to be enabled. You must configure this parameter properly prior to connecting a cable to the MAU port, or data loss may occur.

Monitoring Statistics

This procedure allows you to monitor traffic on the backbone and the segment. The transmit and receive frame information and the number of frame errors detected are continuously displayed and time-stamped for reference.

1. Click on the High-Performance Ethernet I/O module from the node view.
2. Select Monitor from the Tools menu or click on the Monitor icon.

This procedure is identical to the Ethernet I/O module procedure described earlier in this chapter. Refer to Figure 3-5 for an example and Table 3-2 for an explanation of the fields.

Resetting Counters

Select Reset Counts from the Ethernet Monitor screen to reset the counts to zero.

Performing Tests

The Test option allows you to test a new High-Performance Ethernet network before live data is sent out onto it. Test traffic can be generated onto the local High-Performance Ethernet segment or onto the PremNet 5000 fiber backbone.

To initiate an Ethernet test:

1. Select the Ethernet I/O Module as described previously.
2. Select Test from the Tools menu or click on the Test icon.

The system polls the module for the current test status. A Progress box appears showing the percentage of data read.

3. Select one of the options from the Ethernet Test selection. The choices are:
 - Local Segment Test
 - Fiber Backbone Test
 - No Test

This procedure is identical to the Ethernet I/O Module Test procedure previously described within this chapter. Refer to “Performing Tests” within the Ethernet I/O Module section for more detailed information on the specific tests.

Token-Ring 4/16 Mbps I/O Module

The Token-Ring 4/16 Mbps I/O Module connects up to eight token-ring devices to the SNMP PremNet 5000 System.

This section describes how to configure and manage the Token-Ring 4/16 Mbps I/O module.

Configuration Strategy

The following procedure provides an overall strategy when configuring a new Token-Ring I/O module into an existing network. The steps are listed below, after which each step is explained in detail.

1. **Set the I/O data rate to 4 or 16 Mbps.** Refer to “Configuring the Module” within this section.
2. **Perform a loop test.** This test must pass to continue. Refer to “Loop Test” within this section.
3. **Discontinue the loop test.** Refer to “Reset Loop Test” within this section.

4. **Monitor the module connected to the active ring.** This determines that this network is generating proper frame rates with no errors. Refer to “Monitor Ring Statistics” within this section.
5. **Connect the Token-Ring 4/16 Mbps I/O Module to the connection.** Refer to “Configuring Connections” in Chapter 2.
6. **Monitor the module just connected to verify proper frame rates.** Refer to “Monitoring Statistics” within this section.

Configuring the Module

This procedure allows you to configure a Token-Ring 4/16-Mbps I/O Module.

From the node view:

1. Click on the Token-Ring 4/16 Mbps I/O Module.
2. Select Configure from the Tools menu, or click on the Configure icon.

The system displays a screen similar to the one shown in Figure 3-8.




Figure 3-8. Token-Ring 4/16 Mbps I/O Module Configuration Screen

3. Select the correct mode, either 4 Mbps or 16 Mbps.
4. Select the correct RI/RO, either Locked or Unlocked.

Note: Before you change the mode of a module, remove the module from its established connection. Refer to “Deleting Connections” in Chapter 2. Also, the status must be Active before changing the mode.

5. Set the module status to Active or Loopback.

- If you choose **Active** and the module is in Loopback mode, you are prompted for a confirmation.
- If you choose **Loopback**, both the ports and the backplane are looped. This option allows you to test the module by isolating the network from the module. While in Loopback, the Token-Ring is disconnected from the network, allowing you to monitor the integrity of the inserted data.

The Token-Ring should be placed in Loopback mode during initialization of the network. This allows you to step through the network and verify the integrity of the system as modules are brought into operation.

To monitor the Token-Ring network for errors, refer to “Monitoring Traffic” within this section.

6. Choose the port status, either Locked or Unlocked, for all of the ports.

7. Select OK to save the configuration parameters you specified.

Note: If you change the data rate for the module, the following message appears:

WARNING...You have selected a mode change! All other configuration parameters will be set to default values, and the target module will issue no response for approximately 10 sec's.

Displaying the Status

This procedure allows you to display the status of the four MAU ports on the module.

From the node view:

1. Click on the Token-Ring 4/16 Mbps I/O Module.
2. Select **Status** from the Tools menu or click on the Status icon.

The system displays a screen similar to the one shown in Figure 3-9.




Figure 3-9. Token-Ring 4/16 Mbps I/O Module Card Status

3. Select OK to return to the node view.

Monitoring Traffic

You can monitor the frames and errors appearing on the module. The frames and errors are continuously displayed and time-stamped for reference.

From the node view:

1. Click on the Token-Ring 4/16 Mbps I/O Module.
2. Select Monitor from the Tools menu or click on the Monitor icon.

The system displays the monitor screen, as shown in Figure 3-10.




Figure 3-10. Token Ring Monitor

The screen displays the times when the maximum and minimum number of frames occurred, the maximum and minimum counts for frames and errors, and the time when the maximum number of errors occurred.

3. Select Node from the View menu or click on the Node icon to redisplay the previous screen.

Resetting Counters

You can reset the counts to zero by selecting Reset Counts while displaying the Token-Ring 4/16 Mbps I/O Module Monitor screen.

Performing Tests

The following procedures allow you to test the Token-Ring 4-16 Mbps I/O Module before connecting the module into an active ring.

1. Display the Node view and click on the Token-Ring 4/16 Mbps I/O Module.
2. Select Test from the Tools menu or click on the Test icon.

The system polls the module for the current test status (refer to Figure 3-11).

The applicable Token-Ring 4/16 Mbps I/O Module tests include:

- Loop Test
- MAU/Cable
- Reset Test



Figure 3-11. Token Ring Test

Note: These tests are interruptive and will disrupt the normal data flow on the associated unit(s).

Loop Test

The loop test generates an abort frame, which is transmitted through the established ring. The established ring may be either a single I/O module or a multi-point ring. In either case, the loop test places all I/O modules on the ring into loopback, with all ports locked out.

Perform a loop test before connecting the module into an active ring.

From the node view:

1. Click on the Token-Ring 4/16 Mbps I/O Module.
2. Select Test from the Tools menu or click on the Test icon.

Each Token-Ring 4/16 Mbps I/O Module, in sequence, monitors the incoming abort frames. If the incoming signal is free of errors, the signal is passed to the next module in the ring. If errors are detected, the module notifies the system (with an alarm message) and the test initiation signal is not transmitted to the next module, allowing you to isolate a defective I/O module.

To identify the defective I/O module, complete the following steps:

- a. As the test continues to run, access each I/O module in the connection.
- b. View any alarms by selecting Alarms from the Tools menu, or click on the Alarms icon. You can determine the defective I/O module from the alarm messages displayed.
- c. Remove the I/O module from the connection, and the test continues.

Note: Occasionally, a downstream I/O module transmits errors that cause the upstream I/O module to alarm. Contact your System Administrator to determine whether this is the case.

When the abort sequence is received by the initiating I/O module, each I/O module's MAU ports are tested. The incoming abort frames are copied, transmitted through the MAU ports, and compared with the original incoming signal, using two separate frame counts. The frame counts must be equal (± 5 counts) to pass the test.

To monitor the frame counter, choose Monitor from the Tools menu or click on the Monitor icon.

- If the frame counts match, the signal is passed to the next I/O module in the ring.
- If the frame counts do not match, the I/O module responds with an alarm message and the signal is not retransmitted. The frames and errors displayed should be almost identical.

Note: When the module is in Loop Test, the values under the Frames/Second field represent the number of abort frames sent out and the values under the Errors/Second field represent the number of abort frames received.

Reset Loop Test

The loop test continues to run until you select **Reset Test** from the **Token-Ring Test** menu. You may also view the delay time for the ring. Use the delay time to verify that the estimated ring-delay time is accurate. (The estimated ring-delay time is derived by adding up the delay times of each network component.)

Mau/Cable Test

To test the cables connected to the RI/RO ports on a Token-Ring 4/16 Mbps I/O Module:

- Select MAU/Cable.

Note: An active Token-Ring signal must be present in the system before you can run this test. The Token-Ring 4/16 Mbps I/O module must also be in loopback. During the test, the MAU ports are locked out.

Token-Ring 4 Mbps I/O Module

The Token-Ring 4 Mbps I/O Module connects up to eight token-ring devices to the SNMP PremNet 5000 System.

This section describes how to configure and manage the Token-Ring 4/16 Mbps I/O Module.

Configuring the Module

This procedure allows you to configure a Token-Ring 4 Mbps I/O Module.

From the node view:

1. Click on the Token-Ring 4 Mbps I/O Module.
2. Select **Configure** from the **Tools** menu, or click on the **Configure** icon.

The system displays a screen similar to the one shown in Figure 3-12.




Figure 3-12. Token-Ring 4 Mbps I/O Module Configuration Screen

3. Choose the RI/RO status, either Open or Locked.
4. Choose the port status, either Locked or Unlocked, for all of the ports.
5. Select OK to save the configuration.

Refer to “Token-Ring 4/16 Mbps I/O Module” in the previous section for information on the following:

- Displaying the Status
- Monitoring Traffic
- Performing Tests

RS-232 4-Port I/O Module

The RS-232 4-Port Multi-Drop I/O Module offers asynchronous and synchronous data communication via four RS-232 interface ports at speeds up to 38.4 Kbps. The module can also be configured to provide multidrop functionality. You can configure each port on the module independently.

This section describes how to configure and manage the RS-232 4-Port I/O Module.

Configuring the Module

This procedure allows you to set the module's port clocking and port loopback, and to control the module's DTR, RTS, BSY, UNA, DSR, DCD, CTS, and RI signals.

From the node view of the RS-232 4-Port I/O Module:

1. Click on the RS-232 port you want to configure. The port highlights by changing to a darker gray.
2. Select Configure from the Tools menu or click on the Configure icon.

Figure 3-13 is displayed, which allows you to change the configuration.




Figure 3-13. RS-232 Port Configuration

3. Select the type of setup, either Multidrop Central, Multidrop Remote, Non-Standard, or Factory Default.

Note: If you select either Multidrop Central or Multidrop Remote, the Signal Controls are automatically assigned.

4. Select the Clock Mode of the port.
6. Select the Loopback Control, either ON or OFF.
7. Enable or Disable the Streaming Threshold. Enter zero to disable it. Enter a value from 1 to 40 to enable and set the threshold level.
8. Enable or Disable Receiver Enabling.

9. Select the appropriate Signal Controls. Each interface signal can be slaved to another signal, or tied to a mark or space level.
10. Select OK to accept the changes.

Monitoring the Status

This procedure allows you to monitor the activity of the control lines.

From the node view of the RS-232 4-Port I/O Module, or from the port level connection view:

1. Select Monitor from the Tools menu, or click on the Monitor icon.

The Time, Port, DTR, RTS, BSY, UNA, DCD, CTS, DSR, and RI signals received by the module are displayed.

2. Press [ESC] to redisplay the previous screen.

RS-422 I/O Module

The RS-422 I/O Module offers asynchronous and synchronous data communication through four DB-25 connectors. The maximum data rate for asynchronous mode is 256 Kbps, and the maximum data rate for synchronous mode is 2.048 Mbps. You can configure each port on the module independently.

This section describes how to configure and manage the RS-422 I/O Module.

Configuring the Module

This procedure allows you to configure each port of the RS-422 in either the DTE or DCE mode.

Display the node view and select the module. Select the port to configure by clicking on it. The port changes color to a darker gray.

1. Select Configure from the Tools menu or click on the Configure icon.

The RS-422 Port Configuration screen appears. There are two configuration screens, one for a DTE setting and the other for DCE setting. This depends on the default configuration of the module (refer to Figure 3-14).

2. Select the Data Direction desired (DTE or DCE) from the RS-422 Port Configuration screen.

Note: If DTE is in the data direction field, the DCE fields are grayed out. If DCE is in the data direction field, the DTE fields are grayed out.

3. Click on OK to set the data direction of the port.
4. Click on the port again to finish the configuration.
5. Select Configure from the Tools menu or click on the Configure icon. The correct fields appear on the screen.

Configuring the Port for DTE




Figure 3-14. RS-422 Port Configuration (DTE)

1. Select the Clock Mode and the DDS Mode from the General Controls section of the screen (refer to Table 3-4).
2. Configure the DTE Signal Controls.
3. Select Copy To if you want to send the same configuration to another port.
4. Select OK to save the configuration.

Configuring the Port for DCE

Refer to Figure 3-15.




Figure 3-15. RS-422 Port Configuration (DCE)

1. Select the Clock Mode and the DDS Mode from the General Controls section of the screen (refer to Table 3-4).

Note: In the DCE mode of operation, DDS must be set to NO.

2. Configure the DCE Signal Controls (refer to Table 3-4).
3. Select Copy To if you want to send the same configuration to another port.
4. Select OK to save the configuration.

Table 3-4. RS-422/V.35 Configuration Fields

Field	Description
Data Direction	DTE or DCE
Clock Mode	Async, Slave, Ext Sync, 56K to 1024K
DDS	Digital Data Service (Yes or No). Applies to DTE mode only.
DTE Signal Controls Fiber Out 0 Fiber Out 1 Fiber Out 2 Fiber In 0 Fiber In 1 Fiber In 2	<p>Fiber Out 0, Fiber Out 1, and Fiber Out 2 are EIA signals renamed because they are transmitted out through the fiber backbone. The selections are Space, Mark, Slave to CTS, Slave to DSR, Slave to DCD, DTE Mode Only.</p> <p>Example: Setting Fiber Out (0) to Slave to CTS means that CTS is now called Fiber Out (0) because it is going out the fiber backbone.</p> <p>Fiber In 0, Fiber In 1, and Fiber In 2 are EIA Signals renamed because they are received in through the fiber backbone.</p>
Request to Send (RTS) Data Terminal Ready (DTR)	The selections for these fields are Slave to FI(0), Slave to FI(1), Slave to FI(2), Slave to CTS, Slave to DSR, Slave to DCD, and DTE Mode Only.
DCE Signal Controls Fiber Out 0 Fiber Out 1 Fiber Out 2	<p>Fiber Out 0, Fiber Out 1, and Fiber Out 2 are EIA signals renamed because they are transmitted out through the fiber backbone. The selections are Space, Mark, Slave to RTS, Slave to DTR, Slave to UNA (V.35), and DCE Mode Only.</p> <p>Example: Setting Fiber Out (0) to Slave to RTS means that RTS is now called Fiber Out (0) because it is going out the fiber backbone.</p>
Clear to Send (CTS) Data Set Ready (DSR) Data Carrier Detect (DCD)	The selections for these fields are Space, Mark, Slave to FI(0), Slave to FI(1), Slave to FI(2), Slave to RTS, Slave to DTR, Slave to UNA (V.35), and DCE Mode Only.
Delays	Selectable delays in milliseconds for the EIA signals

V.35 4-Port I/ O Module

The V.35 4-Port I/O Module offers asynchronous and synchronous data communication through four V.35 interface ports. The maximum data rate for asynchronous mode is 256 Kbps and the maximum data rate for synchronous mode is 2.048 Mbps. You can configure each port on the module independently.

This section describes how to configure and manage a V.35 4-Port I/O Module.

Configuring the Module

This procedure allows you to configure each port of the V.35 in either the DTE or DCE mode.

Display the node view and select the module. Select the port to configure by clicking on it. The port changes color to a darker gray.

1. Select **Configure** from the Tools menu or click on the **Configure** icon.

The V.35 Port Configuration screen appears. There are two configuration screens, one for a DCE setting and the other for DTE setting. This depends on the previous configuration of the module (refer to Figure 3-16).

2. Select **Data Direction** from the V.35 Port Configuration screen.

Note: If DTE is selected in the data direction field, the DCE fields are grayed out. If DCE is selected in the data direction field, the DTE fields are grayed out.

Configuring the Port for DTE




Figure 3-16. V.35 Port Configuration (DTE)

1. Select the Clock Mode and the DDS Mode from the General Controls section of the screen (refer to Table 3-4).
2. Configure the DTE Signal Controls (refer to Table 3-4).
3. Select Copy To if you want to send the same configuration to another port.
4. Select OK to save the configuration.

Configuring the Port for DCE

Refer to Figure 3-17.




Figure 3-17. V.35 Port Configuration (DCE)

1. Select the Clock Mode and the DDS Mode from the General Controls section of the screen (refer to Table 3-4).

Note: In the DCE mode of operation, DDS must be set to NO.

2. Configure the DCE Signal Controls (refer to Table 3-4).
3. Select Copy To if you want to send the same configuration to another port.
4. Select OK to save the configuration.

4-Wire Voice I/O Module

The 4-Wire Voice I/O Module provides bidirectional transport of voice or voiceband data circuits (300 to 3400 kHz) to another 4-Wire Voice I/O Module in a PremNet 5000 connection.

There are three versions of the 4-Wire Voice I/O module:

- Ear and Mouth (E&M)
- Push-To-Talk (PTT)
- Runway Visual Range (RVR)

These versions support a variety of user applications.

This section describes how to configure and manage the 4-Wire Voice I/O Module.

Configuring the Module

This procedure enables you to assign voice channels to specific ports on the I/O module. You can assign any of the 32 channels to any of the physical ports on the I/O module. To create a point-to-point voice circuit, assign the same channel to each of the two ports. For multiple voice channel drops, assign the same to each physical port on each I/O module that you want to participate in the voice circuit.

Configuring a 4-Wire Voice Card at the Port Level

To configure a 4-Wire Voice I/O module at the port level:

1. Display the node view.
2. Select a port by clicking on the port you want to configure.
3. Select **Configure** from the **Tools** menu or click on the **Configure** icon.

The port level connection view of the selected module is displayed (refer to Figure 3-18).




Figure 3-18. 4-Wire Port Configuration

4. Enter a channel number, 1 to 32, in the Connect Channel Field.
5. Select the Mouth setting (Free, F0, or F1).
 - If Free, the electrical signal is transmitted at the non-active (0) or the active (1) state, depending on the state of the electrical signal that is transmitted by the attached external equipment.
 - If F0, the electrical signal will be forced to a non-active state.
 - If F1, the electrical signal will be forced to an active state.
6. Type the value for the RX Gain Signal and the TX Gain Signal.
 - RX Gain is added to the Pulse Code Modulation (PCM) signal before it is output to the line.
 - TX Gain is added to the line signal before it is digitized and sent to the PCM channel. The 4-Wire Voice I/O module uses the PCM encoding method of conversion, which uses 0 dBm or 1 milliwatt as its reference. These are the factory-set defaults.

With 0 dBm as the reference, the 4-Wire Voice I/O Module has a dynamic range of +2.5 dBm to -23 dBm, and can receive and transmit signals within this range without distortion. If the external attached equipment produces a signal with a signal level that is outside these parameters, you may need to adjust the system gain on the data port.

Note: The RX and TX Reference Signal field values are factory-set defaults and provide a 0.0-dBm reference of 1 milliwatt. Each number increment represents 0.1 dB. To maintain this relative calibration, do not change the reference number.

7. Select the law companding method (μ -Law, A Law EBI, A Law Not EBI).

Companding is the process of compressing analog signals for digital transmission and decompressing digital signals for transmission to the attached analog equipment. μ -Law is the standard companding method used in the United States. A-law is the standard companding method used in Europe.

- Select A-not even bit inv to set the active companding method to A-law with no Even Bit Inversion.
 - Select μ -Law to set the active companding method to μ -Law.
 - Select A-even bit inv to set the active companding method to A-law, including Even Bit Inversion.
8. Select OK to save the configuration.

Video I/O Module

Video I/O Modules enable you to communicate video/audio information from a central site to groups of users at remote sites. The Video I/O Modules come in three types: 2-Way Video, 1-Way Video Input, and 1-Way Video Output. This section covers all three types.

Configuration Strategy

This procedure provides the steps necessary to establish Video I/O connections.

- 1. Verify bandwidth requirements.** Refer to “Configuring the Module” within this section to select the bandwidth required by the application. The default setting is six time slots (compression 12:1).
- 2. Set up the Video I/O Module for the application configuration.** Refer to “Configuring the Module” within this section.

Configuring the Module

To configure any of the Video I/O Modules:

1. Display the node view and click on the Video I/O Module.

2. Select Configure from the Tools menu, or click on the Configure icon.

The Video Configuration screen appears (refer to Figure 3-19). Table 3-5 describes the modifiable parameters.



Figure 3-19. 2 Way Video I/O Module Configuration Screen

Table 3-5. Configure Video I/O Module Parameters

Field	Description
Timeslots	Select the number of time slots: 2, 4, 6, or 8. The default time slot setting of six provides enough bandwidth to produce quality images.
Standard	Select the video standard displayed on the screen. Select (NTSC) National Television Systems Committee (US), or (PAL) Phase Alternative Line (Europe).
GENLock	Enable the external GEN clock that is used to synchronize video, or use the internal clock.
Display	Select color or black and white. Set according to what the input source transmits.
Audio Input	Select the input port that will be used to receive sound. These ports are standard ¼-inch stereo audio jacks.
Mute	Enable or disable the audio signal received from the fiber and transmitted to the audio out port.
Audio Sample	Select either 8-bit companded or 16-bit companded.
Baud Rate	Select a baud rate (300, 1200, 2400, 4800, or 9600).
Parity	Select parity (None, Odd, or Even).
# of Bits	Select either a 7 bit or 8 bit format.
Audio Loopback	Allows you to check and adjust audio signals before setting connections. If enabled, the audio IN port is logically connected to the audio Out port.
Module Reset	Allows you to reset the module if you experience freeze-frame in the video.
Passthru State	Select ON or OFF to configure the video application for multipoint.
Broadcasting	Select ON or OFF to configure a broadcast session. This option does not apply to 1-Way Video Output.

T1/E1 I/O Module

T1 and E1 are used to differentiate between North American (T1) and European (E1) hierarchical voice/data transmission systems used in the digital telephone network.

The physical module will be a DS1, a DS1A, or a G.703. Configuration and management of all three modules is the same.

This section describes how to manage and configure the T1/E1 I/O Module.

Configuring the Module

This procedure allows you to configure the T1/E1 I/O Module thresholds, error detection/source, loopback mode, and cable length.

To configure the module:

1. Display the node view and select the port to configure by clicking on it. The port changes color to a darker gray.
2. Select **Configure** from the Tools menu, or click on the Configure icon.

The T1/E1 I/O configuration screen is displayed (refer to Figure 3-20). The Bipolar Pulse Violation Error per second (BPVE/sec) threshold field is highlighted.

Note: BPV is a bipolar pulse with the same polarity as the preceding pulse. This is a violation of the Alternate Mark Inversion rule.




Figure 3-20. DS1 Port Configuration

3. Enter a number between 1 and 32000 for the BPVE threshold limit. An alarm occurs when this limit for BPVE/sec. is exceeded.
4. Select the Error Detection Algorithm, either B8ZS or AMI, for the bipolar violation error detector on the port.

Note: This must match the type of bipolar signal being transported, or errors will be reported. (However, failure to properly select this option will not cause errors to be induced in the actual transported signal.)

5. Select the error detect source, either Remote or Local.
6. Select the loopback mode, either Remote or Local.
 - Remote allows you to place a far-end port in a loopback state such that it will return data to the near end. When invoked, input and output LEDs on the T1/E1 module flash continuously.
 - Local loops TX data locally and appears at the local RX port on the connector. When invoked, input and output LEDs on the T1/E1 module flash continuously.
7. Select either YES or NO for Tx All 1s on LOS.
8. Select the Cable Length (0-133ft, 133-266ft, 266-399ft, 399-553ft or 533-655 ft).
9. Select OK to accept the configuration.

Monitoring the Status

This procedure allows you to monitor Bipolar Violation Errors (BPVE) relative to realtime, and displays the calculated error-free seconds (EFS) and elapsed time (ET) since the last reset occurred.

To monitor the status:

1. Display the node view and click on the T1/E1 I/O module.
2. Select a port by clicking on it. The port will change color to a darker gray.
3. Select Monitor from the Tools menu or click on the Monitor icon.

The Time, Port Elapsed Time, and Bipolar Violations signals received by the T1/E1 I/O module are displayed.

4. Select Reset Counts to reset the counts.

The message is displayed: "Are you certain? Press Y to confirm. Any other key to cancel".

5. Select Cancel to return to the previous screen.

Performing Tests

This operation allows you to perform a complete self test of the established TX and RX circuit paths for the near-end and far-end modules.

Note: The port at the remote end must be looped back before this test can run.

To initiate a test:

1. Display the front view of the T1/E1 I/O Module:
2. Select a port by clicking on the desired port.
3. Select Tools/Test from the menu, or click on the Test icon.

The message is displayed: “The port at the remote end must be looped back for this test”.

4. Select OK to continue.

A pattern is generated at the near end and is sent to the far end, where it is looped back to the near end and analyzed for error content. When the test is complete, the results are displayed (whether the test passed or failed and whether there were any data or BPV errors).

3270 8/32-Port I/O Module

The 3270 8/32-Port I/O Module enables you to connect 3270 devices to the PremNet 5000 System. 3270 refers to a series of similar interfaces that are common to the 3x7x-series physical and electrical interface protocols.

This section describes how to configure and manage the IBM 3270 8/32-Port I/O Module.

Configuring the Module

To set the 3270 8/32-Port I/O Module's mode to control the terminal, 3274 Controller, 3174 Controller, Mux with 3299, and Mux without 3299:

1. Display the node view and click on the 3270 8/32-Port I/O Module.
2. Select Configure from the Tools menu or click on the Configure icon.

The card configuration screen is displayed (refer to Figure 3-21). This screen applies to both the 8-Port and 32-Port modules. The Port Configuration screens follow.




Figure 3-21. 3270 Card Configuration Screen

3. Select one of the following from the 3270 Mode field:
 - 3274
 - 3271
 - Mux with 3299
 - Mux w/o 3299
 - Terminal
4. Select each of the four Receiver Bias fields and choose Enable or Disable.
5. Select each of the four Logical Group fields and choose Enable or Disable.
6. Click on OK to accept the card configuration.

The port configuration for the 8 Port card and the 32 Port cards are slightly different.

Establishing Port Connections

8-Port Card

1. Click on the port you want to configure.
2. Select Configure from the Tools menu or click on the Configure icon. The port configuration screen appears (refer to Figure 3-22).




Figure 3-22. 3270 Port Configuration

3. Select the Port Enable field and choose Enable or Disable.
4. Select the Port Polarity field and choose Normal or Reversed.
5. Select the Transmit Delay field and choose Cleared or Set.
6. Select the Rcvr Fast Check field and choose Cleared or Set.
7. Select the Logical Channel field and enter a channel number between 1 and 32.
8. Select OK to save the configuration.

32-Port Card

1. Click on the port section you want to configure, either 1-16 or 17-32.
2. Select **Configure** from the Tools menu or click on the Configure icon. The port configuration screen for your selected section appears. This screen reappears after each port configuration. Select **Cancel** when port configuration is complete. Refer to Figure 3-23 for port selection.




Figure 3-23. Port Selection

3. Click on the port you want to configure.
4. Select OK to bring up the port configuration screen. Refer to Figure 3-22, Port Configuration.

5250 8-Port and 4-Port I/O Modules

The 5250 I/O Module transports the 5250 serial bit stream from an AS/400 across the fiber backbone using one TDM time slot.

This section describes how to configure and manage the 5250 8-Port and 4-Port I/O Modules.

Configuration Strategy

The following procedure provides an overall strategy when configuring a new 5250 8-Port/4-Port I/O Module into an existing network. Review the steps carefully. Each step is broken down into a more detailed procedure.

1. **Configure the interface type.** Refer to “Configuring the Module” within this section.
2. **Establish a connection.** Refer to “Configuring Connections” in Chapter 2 for more detail.
3. **Establish port-level connection between the controller module and the peripheral modules.** Refer to “Enabling/Disabling All Ports” within this section.
4. **Enable the ports.** Refer to “Changing the Port Configuration” within this section.

Configuring the Module

To change the module type:

1. Display the node view and click on the 5250 I/O Module.
2. Select Configure from the Tools menu or click on the Configure icon. The 5250 Card Configuration screen appears (refer to Figure 3-24).




Figure 3-24. 5250 Card Configuration

3. Select the Module Type field and choose Controller, Peripheral or Mux.

Depending on the module type selected, the module will operate in a different manner:

- Select Peripheral if the connecting workstations or peripheral devices are in a daisy-chain configuration. Each port will extend the controller's port, allowing the same seven devices to be connected in series.

Each peripheral module in the connection compares the port address of the received backplane data with its port map connection (see "Establishing Port Connections" within this section).

If the address compares, the data is received off the backplane and processed to the interface. In all cases, the data received from the backplane is retransmitted onto the backplane in the next available time slot (loop through). The Controller module prevents data from circulating unnecessarily.

- Select Mux to allow direct connection of workstations to the individual ports. Each port will support one workstation or peripheral device.

- Select Controller to allow the module to connect to the AS400 workstation controller.

Note: All ports on the controller module must be physically connected to the same AS400 Controller. Separate controllers cannot share the same module. Only one controller module is allowed in the same connection.

4. Select the Connections field and choose Do Not Reset or Reset.
5. Select the Reset Count field and choose Do Not Reset or Reset.
6. Select OK to save the configuration.

Establishing Port Connections

The modules maintain a port-level connection (port 1 to port 1, port 2 to port 2, etc.). This procedure allows you to determine which ports on the controller module are going to be connected at the different peripheral modules.

1. Click on the port you want to configure. The Port Configuration screen appears, as shown in Figure 3-25.
2. Select the Port Lockout field and choose Enable or Disable.
3. Select the Port Connection field and choose Add or Delete.
4. Select OK to save the configuration.

Repeat steps 1 through 4 for each additional port to configure.



Figure 3-25. Establishing Port Connections

Note: If you are displaying a 5250 4-Port I/O Module, only Ports 1-4 are available to add or delete the connection.

Reset Rx Frame Synchronization

To reset the Rx frame synchronization error count:

1. Display the node view and click on the 5250 I/O Module.
2. Select **Configure** from the Tools menu or click on the Configure icon. The card configuration screen appears (refer to Figure 3-24, 5250 Card Configuration).
3. Select the Reset Count field and choose **Reset**.

ATM I/O Module

The Asynchronous Transfer Mode (ATM) I/O Module enables you to send and receive short, fixed-length packets called “cells” using the ATM transport.

This section describes how to configure and manage the ATM I/O Module.

Configuration Strategy

This procedure outlines the steps to establish ATM connections. The steps are listed below, after which each step is explained in detail.

1. **Configure the ATM Module.** Refer to “Configuring the Module Settings” within this section to define the number of time slots and cell-shaping parameters.
2. **Configure the Virtual Paths.** Refer to “Configuring the Virtual Path” within this section to add or delete ATM Virtual Paths.

Note: Once the connections have been assigned, you cannot change the Module’s bandwidth without deleting the connection.

Note: Disable the Loopback before establishing a connection.

Configuring the Module Settings

This procedure describes how to specify the following module settings:

- The UNI interface type, DS3 (45 Mbps) or Fiber (100 Mbps). This option is applicable to the 850082 module only.
- The number of time slots.
- The module's power setting, line length, and enable/disable the cell payload scrambler (DS3 only).
- The cell-shaping percentage for the ATM network.

To configure the module settings:

1. Display the node view and click on the ATM I/O Module.
2. Select Configure from the Tools menu, or click on the Configure icon.

The ATM Configurators screen appears (refer to Figure 3-26).




Figure 3-26. ATM Configurators

3. Select Do Card Configuration from the ATM Configurators screen.

The ATM Interface Configuration screen appears (refer to Figure 3-27).




Figure 3-27. ATM Interface Configuration

4. Click on each field of the screen and enter the appropriate settings (refer to Table 3-6).

Table 3-6. Configuration Modifiable Parameters

Parameter	Description
Time Slots	Allows you to allocate time slots to the ATM I/O Module. This option is available only in Standby mode. Note: Changing the time slots causes the module to momentarily lose communication with the Network Management Module (NMM).
Interface Type	Specify the UNI interface type, DS3 (45 Mbps) or Fiber (100 Mbps). This option is applicable to the 850082 module only.
Tx Clock Source	Specify whether the Tx clock for the module is externally or internally sourced.
Cell Shaping	Allows you to allocate link bandwidth to the module. For example, on the Fiber Tx interface, which operates at 100 Mbps, you can specify cell-rate shaping on the ATM I/O module for up to a maximum of 34.5% of the bandwidth used for non-idle cells. This means that the active cell rate leaving the ATM I/O Module port would always be less than or equal to 34.5 Mbps.
DS3 Line Length	Specify whether you are using a short cable (less than 225 feet) or a long cable (more than 225 feet) for the DS3 connectors.
LIU Power	Select either a high or low power setting for LIU (Link Interface Unit) ATM Modules.
Cell Payload Scrambler	Allows you to select whether or not to use the payload scrambler. This is available in DS3 mode only.
Loopback Mode	Allows you to perform loopback testing on either the ports or the backplane of the current ATM Module.
Obtain Remote VPIs	Allows you to query the network for connections to the local ATM Module.

5. Select OK to save the configuration.

Configuring the Virtual Path

To configure the virtual path:

1. Display the node view and click on the ATM I/O Module.

Note: This module is the local ATM Module.

2. Select Configure from the Tools menu or click on the Configure icon.

The ATM Configurators screen appears (refer to Figure 3-28).




Figure 3-28. ATM Configurators

3. Select Do Virtual Path Configuration from the ATM Configurators screen. The Virtual Path Configuration screen appears (refer to Figure 3-29).




Figure 3-29. Virtual Path Configuration

Adding a Virtual Path

1. Select Add VPI. The Add VPI, Delete VPI, View Table, and Cancel fields gray out, and the Add Virtual Path section highlights (refer to Figure 3-30).




Figure 3-30. Virtual Path Configuration (ATM Modules)

2. Enter a number between 1 and 256 in the Local VPI field. This number is arbitrary. Its function is to keep track of which module is which, local or remote.
3. Enter a different number between 1 and 256 in the Remote VPI field. This number is arbitrary. Its function is to keep track of which module is which, local or remote.
4. Highlight Remote ATM Module from the list in the field.
5. Select Add to save the Virtual Path.
6. Select View Table to see a list of the Virtual Paths.
7. Select Cancel to return to the Node View.

Deleting a Virtual Path

1. Select View Table to see the existing virtual paths.
2. Highlight a virtual path to delete.
3. Select Delete VPI to delete the virtual path.
4. Select Cancel to return to the Node View.

SONET/SDH Link Module

The SONET/SDH (OC3) Link Module converts PremNet backplane data into SONET or SDH frames (mode is software-selectable), which are transmitted at 155 Mbps over fiber optic cable.

Note: SONET is an acronym for Synchronous Optical Network. SDH stands for Synchronous Digital Hierarchy.

Configuration Strategy

This procedure describes how to configure and manage the SONET/SDH link module. Review the steps carefully. The steps are listed below, after which each step is explained in detail.

1. **Select the target link module.** Refer to “Displaying the SNMP PremNet I/O and Link Module” within this chapter.
2. **Set the link module to the desired operating mode.** Select either SONET (United States) or SDH (Europe). Refer to “Configuring the Module” within this section.
3. **Select the type of ring topology for your network.** Configure the link to single-link (one link per node) or counter-rotating links (two links per node). Refer to “Configuring the Module” within this section.
4. **Initialize unused overhead bytes.** Refer to “Configuring the Module” within this section.
5. **Select the timing clocks for the target link module.** Specify/change the timing clock source for the link module. Refer to “Configuring the Module” within this section.

Configuring the Module

To configure the SONET/SDH Link Module:

1. Display the node view and click on the SONET/SDH Link Module.
2. Select Configure from the Tools menu or click on the Configure icon. The OC3 SONET/SDH Link Configuration screen is displayed (refer to Figure 3-31).




Figure 3-31. OC3 SONET/SDH Link Configuration

3. Select the Mode field and choose either SONET (US) or SDH (Europe).
 4. Select the Timing Control field and choose one of the following:
 - Master=Internal/Slave=Line - The appropriate transmit clock is automatically selected.
 - Line Timing - The transmit SONET/SDH clock source is the clock recovered from the received signal.
 - Internal Clock - The transmit SONET/SDH clock source is the module's internal 20 ppm oscillator.
 - BITS Clock (SONET only) - The transmit SONET clock source is the clock recovered from the BITS clock input. This option is not displayed if the link module is set to SDH mode.
- If you select the BITS clock, the new timing mode becomes effective immediately.
5. Select the Ring Mode field and choose Single or Counter/Rotating.

Note: Single-link configurations do not support protection switching or the Bellcore performance monitoring requirements.

In a PremNet node that has two link modules installed (either in Slots A-B or in C-D), do not attempt to configure one or both links on a single-link ring. This is not a valid configuration and may cause system problems.

6. Select the Overhead Init Value field and choose 0 or FF.

Overhead Initialization Value - This option allows you to “stuff” the SONET overhead bytes that are not used by the link module. According to Bellcore specifications, these bytes must be filled with either zeros (0s) or ones (hexadecimal Fs).

7. Select the Terminal Loopback field and choose ON or OFF. Terminal Loopback loops the signal from transmit port to receive port on the selected Link Module. This tests the local SONET/SDH data path and associated hardware.
8. Select the Facility Loopback field and choose ON or OFF. Facility Loopback is run between two link modules. The signal goes from Tx on module one to Rx on module two, and back again from Tx on module two to Rx on module one.
9. Select OK to save the configuration.

T3 Link Module Configuration

To configure the T3 Link Module:

1. Display the node view and click on the T3 Link Module.
2. Select **Configure** from the Tools menu or click on the Configure icon. The T3 Link Configuration screen is displayed (refer to Figure 3-32). The Line Build Out field is highlighted.




Figure 3-32. T3 Link Configuration

3. Select the appropriate cable length.

Cable < 225'
Cable > 225'

4. Select the appropriate Power Output level. Normally this selection is low. Select High Power if the cable length is greater than 225 feet.
5. Select the appropriate Timing Control from the following:

Auto/Master Internal/Slave Recovered - is the default clock source. The module selects the clock, either Internal or Recovered, automatically.
Internal Clock - is the module's internal 44.736 MHz clock.
Recovered clock - is the clock recovered from the received signal.

6. Select the appropriate Ring Mode, either Single or Counter Rotating.
7. Select the appropriate Terminal Loopback state, either ON or OFF.

The terminal loopback test loops data from the Switch module through the T3 and back to the Switch module. This tests all the T3 Link module except the physical interface.

8. Select the appropriate Facility Loopback state, either ON or OFF.

The facility loopback test connects the incoming T3 received signal to the T3 transmitter in the return direction. This loopback requires at least two T3 Link Modules.

9. Select OK when you are finished with the configuration.

Introduction

There are two types of reports:

- Network Revision Report
- Nodal Configuration Report

Network Revision Report

The Network Revision Report displays a list of cards and their locations, based on the selected criteria. It is used, for example, when the operator wants to know which ENMM cards have a software revision earlier than Rev. 3.5. The user enters this range. The application searches the network and reports the location of all the appropriate ENMM cards. The report displays a list by Ring, Node, and Position.

Generating a Network Revision Report

1. Select Reports from the Tools menu.
2. Select Network from the Reports menu.
3. Enter the criteria range from the following selection:
 - No Criteria Fields
 - Serial number
 - Software revision
 - Hardware revision
4. Select All Equipment or choose from the Equipment Selection List (refer to Figure 4-1).
5. Enter a Range of numbers corresponding to the criteria selection if needed. Example: Serial numbers from 10700500 to 10700600.
6. Select OK to run the report (refer to Figure 4-2).

Refer to Table 4-1 for an explanation of each field.




Figure 4-1. Network Revisions Report Selection




Figure 4-2. Network Revisions Report

Table 4-1. Network Revision Report Information

Detail	Description
Ring	Ring of the selected equipment.
Node	Node of the selected equipment.
Position	Position of the selected equipment in the node.
ID	Type of equipment in the specified position.
S/N	Serial number of the equipment.
S/W	Software revision of the equipment.
H/W	Hardware revision of the equipment.

Nodal Configuration Report

When a node is selected, the Nodal Configuration Report displays the hardware and software revision levels for all the cards in the node, along with other important information. This is useful when troubleshooting the network.

Generating a Nodal Configuration Report

1. Select **Reports** from the Tools menu.
2. Select **Nodal** from the Reports menu.

Note: A nodal view must be displayed to generate a nodal report.

An example of a Nodal Configuration Report is displayed in Figure 4-3, and the report information is described in Table 4-2.




Figure 4-3. Nodal Configuration Report

Table 4-2. Nodal Configuration Report Information

Detail	Description
Position	Position of the module.
ID	Type of module in the specified position.
Cnfg.	Configuration of the node. There are only two options: <ul style="list-style-type: none"> • CRR (Counter Rotating Ring) or • REDNT (Redundant)
Status	Indicates whether the module is active, on standby, or in alarm status
S/N	Serial number of the module.
S/W	Software revision of the module.
H/W	Hardware revision of the module.

Cancel Reports

You can prematurely terminate the gathering of information. This feature is also useful if, for example, the node is not responding or the network is slow to respond.

To cancel a report, select **Cancel** from the **Tools** menu.

Index

3		
3270 8/32 Port I/O Module		
configure	3-41	
3270 8/32-Port I/O Module		
description	1-7	
4		
4-Wire Voice I/O Module		
configure	3-34	
description	1-7	
port level configuration	3-34	
5		
5250 8 Port and 4 Port I/O Modules		
configure	3-44	
establishing port connections	3-46	
5250 8-Port and 4-Port I/O Modules		
description	1-8	
resetting Rx frame synchronization.....	3-47	
A		
Asynchronous Transfer Mode.....	<i>See</i> ATM	
ATM I/O Module		
description	1-8	
virtual path.....	3-50	
Autodiscovery		
HP OpenView	2-2	
B		
Backbone Test		
Ethernet I/O Module.....	3-12	
BPVE		
definition.....	3-39	
C		
Cancel		
description	2-29	
CMS 400 Database		
adding SNMP PremNet 5000	2-2	
Commands		
service affecting.....	2-12	
communication utilities.....	1-4	
Configure		
3270 8/32 Port I/O Module.....	3-41	
4-Wire Voice I/O Module.....	3-34	
4-Wire Voice I/O Module at port level.....	3-34	
5250 8 Port and 4 Port I/O Modules	3-44	
description.....	2-26	
Ethernet I/O Module	3-5	
High-Performance Ethernet I/O Module ..	3-12	
RS-232 4-Port I/O Module.....	3-26	
RS-422 I/O Module.....	3-27	
T1/E1 I/O Module.....	3-39	
T3 Link Module	3-55	
Token-Ring 4 Mbps I/O Module	3-24	
Token-Ring 4/16-Mbps I/O Module	3-17	
V.35 I/O Module	3-31	
Video I/O Module	3-36	
Connections		
add connections.....	2-16	
delete connections	2-20	
modify connections	2-19	
rename connections.....	2-22	
Criteria		
description.....	2-27	
Customize Rascal.....	2-3, 2-27	
D		
Details		
description.....	2-25	
Direct SNMP		
description.....	2-28	
Display		
Token-Ring 4/16 Mbps I/O Module status	3-19	
E		
Enhanced Network Management Module		
description.....	1-3	
Ethernet I/O Module		
configure	3-5	
description.....	1-5	
monitoring statistics.....	3-7	
performing tests	3-10	
resetting counters	3-9	
H		
Halt Current Test		
Ethernet I/O Module	3-12	

High-Performance Ethernet I/O Module
 configure 3-12
 description 1-6
 monitoring statistics 3-16
 resetting counters 3-16
 tests 3-17

I

I/O Modules
 3270 8/32 Port 3-41
 4-Wire Voice 3-34
 5250 8 Port and 4 Port 3-44
 Asynchronous Transfer Mode (ATM) 3-47
 Ethernet 3-5
 High-Performance Ethernet 3-12
 port level display 3-2
 RS-232 4-Port Multi-Drop 3-25
 RS-422 3-27
 T1/E1 3-38
 Token-Ring 4 Mbps 3-24
 Token-Ring 4/16 Mbps 3-17
 V.35 3-31
 Video 3-36

Interconnect Node
 description 1-2

L

Link Module
 SONET/SDH 3-53
 T3 3-55

Local Segment Test
 Ethernet I/O Module 3-10

Loop Test
 Token-Ring 4/16-Mbps I/O Module 3-22

M

Mau/Cable Test
 Token-Ring 4/16 Mbps I/O Module 3-24

MIB, defined 2-4

Monitor
 description 2-24
 Ethernet I/O Module statistics 3-7
 High-Performance Ethernet I/O Module
 statistics 3-16
 RS-232 4-Port I/O Module 3-27
 T1/E1 I/O Module status 3-40
 Token-Ring 4/16 Mbps I/O Module traffic 3-20

Multi-Ring View

display 2-7
 service affecting commands 2-12

N

Network
 report 4-1

Network Node
 description 1-3

Node
 report 4-3

Node Types
 description 1-2

Node View
 display 2-11
 service affecting commands 2-14

P

Ping
 description 2-27

Port
 establishing 5250 I/O Module connections 3-46

R

Refresh
 description 2-29

Reports
 Cancel 4-5
 Network Revision Report 4-1
 Nodal Configuration Report 4-1

Reset Loop Test
 Token-Ring 4/16-Mbps I/O Module 3-24

Resetting Counters
 Ethernet I/O Module 3-9
 High-Performance Ethernet I/O Module .. 3-16
 Token-Ring 4/16 Mbps I/O Module 3-21

RS-232 4-Port I/O Module
 configure 3-26
 description 1-6
 monitor the status 3-27

RS-422 I/O Module
 configure 3-27
 description 1-6

Rx Frame Synchronization
 resetting 5250 I/O Module 3-47

-
- S**
- Service Affecting Commands
 - description 2-12
 - network configuration 2-12
 - node configuration..... 2-14
 - ring configuration 2-13
 - warning display..... 2-12
 - Single-Ring View
 - display..... 2-8
 - service affecting commands 2-13
 - SNMP command stack..... 1-4
 - SNMP PremNet 5000
 - accessing via CMS 400..... 1-4
 - defining in the CMS 400 database..... 2-2
 - managing the network 2-1
 - SONET/SDH Link Module
 - configure 3-53
 - definition..... 3-53
 - description 1-9
 - stack, SNMP command..... 1-4
 - Status
 - description 2-25
 - Status Display
 - Token-Ring 4/16 Mbps I/O Module..... 3-19
 - System Master Node
 - description 1-2
- T**
- T1/E1 I/O Module
 - configuring..... 3-39
 - description 1-7
 - monitoring the status 3-40
 - tests 3-41
 - T3 Link Module
 - configure 3-55
 - description 1-9
 - Tests
 - description 2-26
 - Ethernet I/O Module..... 3-10
 - High-Performance Ethernet I/O Module.. 3-17
 - T1/E1 I/O Module 3-41
 - Token-Ring 4/16-Mbps I/O Module 3-22
 - Token-Ring 4 Mbps I/O Module
 - configure..... 3-24
 - Token-Ring 4/16 Mbps I/O Module
 - monitoring traffic..... 3-20
 - resetting counters..... 3-21
 - Token-Ring 4/16-Mbps I/O Module
 - configure 3-17
 - description..... 1-6
 - tests..... 3-22
 - Token-Ring 4-Mbps I/O Module
 - description..... 1-6
 - Tools Menu
 - for I/O and link modules 3-3
 - Traps 2-30
- U**
- utilities, communication 1-4
- V**
- V.35 I/O Module
 - configure 3-31
 - description..... 1-7
 - Video I/O Module
 - configure 3-36
 - description..... 1-7
 - Virtual Path
 - adding..... 3-51
 - configuration 3-50
 - configure 3-50
 - deleting..... 3-52
- W**
- Warnings
 - service affecting commands..... 2-12
 - Workgroup Node Manager, overview 1-3

We want your feedback.

To better serve our customers, Milgo Solutions welcomes your comments concerning this manual. Please take the time to fill out the following questionnaire, remove it from your manual, and drop it in the mail or FAX it to us at (954) 846-3244. We also welcome your comments via e-mail at address *techdoc@milgo.com*.

Name of Manual/Document No./Date:

SNMP PremNet 5000 Manager for Windows User's Guide 13D475A-7/B 12/96

Was the information in this manual presented in a logical order?

_____ Excellent _____ Good _____ Fair _____ Poor

How easy was it to locate specific information?

_____ Very easy _____ Moderately easy _____ Difficult

Rate the technical level of information presented in this manual:

_____ Too technical _____ Suitable technical level _____ Not technical enough

Are technical terms clearly defined?

_____ Excellent _____ Good _____ Fair _____ Poor

Rate the quality of the illustrations:

_____ Excellent _____ Good _____ Fair _____ Poor

Are the manual's instructions clearly written?

_____ Excellent _____ Good _____ Fair _____ Poor

Rate the quantity of the illustrations in this manual:

_____ Too many _____ Suitable amount _____ Not enough

Does this manual contain all the information you require? (Y/N)

If not, what would you suggest we add to make the manual more useful?

Did you find any errors in this manual? (Y/N)

If yes, please note the error and page number in the space provided below:

NAME _____ TITLE _____

COMPANY _____

ADDRESS _____

CITY _____ STATE _____ ZIP _____

TELEPHONE NO. () _____

Tape Here

- FOLD




No
Postage Stamp
Necessary
If Mailed In The
United States

BUSINESS REPLY MAIL
FIRST CLASS MAIL PERMIT NO. 8699, FT. LAUDERDALE, FLORIDA

Postage Will Be Paid By Addressee

MILGO Solutions, Inc.

Attn: Technical Writing, MS-D108
Post Office Box 407044
Fort Lauderdale, FL 33340-7044



-